

EPSON®

INK JET PRINTER

STYLUS® PHOTO R2400

User's Guide

Copyright Notice

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson printer. Epson is not responsible for any use of this information as applied to other printers.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

A Note Concerning Responsible Use of Copyrighted Materials

Epson encourages each user to be responsible and respectful of the copyright laws when using any Epson product. While some countries' laws permit limited copying or reuse of copyrighted material in certain circumstances, those circumstances may not be as broad as some people assume. Contact your legal advisor for any questions regarding copyright law.

Trademarks

Epson, Epson Stylus, Epson UltraChrome, and Epson UltraChrome Hi-Gloss are registered trademarks, and Epson UltraChrome K3 and Exceed Your Vision are trademarks of Seiko Epson Corporation.

Peizo Pro, BorderFree, RPM, and UltraSmooth are registered trademarks, PhotoEnhance is a trademark, and Epson PhotoCenter and Epson Connection are service marks of Epson America, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.



Contents

Welcome!	7
About Exif Print	8
About Your Software	8
About Your Documentation	9
Viewing the On-screen Reference Guide	10
Loading Paper	11
Loading Paper in the Sheet Feeder	12
Loading Special Paper in the Sheet Feeder	14
Loading Multiple Sheets of Matte Paper	15
Loading Special Paper in the Single Sheet Guide	17
Loading Roll Paper or Canvas	21
Loading Thick Media in the Front Path	25
Printing From Start to Finish	27
Basic Printing in Windows	28
Selecting the Settings You Use Most Often	30
Customizing Your Windows Print Settings	31
Basic Printing With Mac OS X	33
Customizing Your Macintosh Print Settings	39
Selecting the Correct Paper Type	41
Printing Special Photos	43
Printing on Roll Paper	43
Selecting Roll Paper Print Settings	44
Removing Your Printed Photos	48
Removing and Storing Roll Paper	48

Printing Borderless Cut Sheets	49
Windows	50
Mac OS X	51
Managing Color With Profiles	53
Printing With a Color Profile	53
Solving Color Management Problems	62
Printing a Custom Profile Test Target	62
Creating a Custom Profile	66
Easy Printing With Photoshop Elements 3.0	67
Matching Black Ink to Paper Type	68
Swapping the Black Ink Cartridges	70
Confirming the Swapped Cartridge Settings	71
Advanced Black and White Photo Printing	73
Windows	74
Mac OS X	76
Maintaining Your Printer	79
Cleaning the Print Head	79
Automatically Checking and Cleaning the Print Head	80
Running the Head Cleaning Utility	81
Replacing an Ink Cartridge	82
Checking the Ink Cartridge Status	83
Purchasing Ink Cartridges	83
Ink Cartridge Precautions	84
Removing and Installing Ink Cartridges	84
Aligning the Print Head	86
Automatically Aligning the Print Head	86
Manually Aligning the Print Head	87
Cleaning the Printer	88
Transporting the Printer	89

Solving Problems	91
Printer Parts	92
Printer Buttons	93
Printer Lights	94
Diagnosing Printer Problems	94
Running a Printer Check	96
Problems and Solutions	97
Setup and Software Installation Problems	97
Printer Problems	98
Quality Problems	99
Paper Problems	101
Miscellaneous Problems	104
Uninstalling and Reinstalling Printer Software	105
Where To Get Help	106
Epson Technical Support	106
Technical Support for Other Photo Software	107
Requirements and Notices	109
Windows System Requirements	109
Macintosh System Requirements	109
Important Safety Instructions	110
Ink Cartridge Safety Instructions	111
FCC Compliance Statement	112
Declaration of Conformity	113
Epson America, Inc. Limited Warranty	113
Index	115

Welcome!

Your Epson Stylus® Photo R2400 gives you beautiful archival prints on a wide variety of glossy and matte papers in many sizes.

Your outstanding printouts result from these advanced features:

- Nine individually replaceable Epson® ink cartridges let you print at up to 5760 × 1440 dpi (dots per inch).
- Large gamut, pigment-based, Epson UltraChrome K3™ inks and compatible papers deliver brilliant, long-lasting, water-resistant prints.
- Light Black, Light Light Black, and either Photo Black or Matte Black ink cartridges provide neutrality and tonal scale accuracy for demanding black and white photographs.
- Advanced printing options give you control over grayscale color tonalities (such as cool, neutral, warm, and sepia).
- Large format and thick media capabilities let you print panoramics, portraits, and specialty prints up to 13 × 44 inches.
- Versatile paper handling lets you create BorderFree®, frame-ready prints in popular sizes, including 4 × 6, 5 × 7, 8 × 10, Letter, 11 × 14, 12 × 12, 13 × 19, and others.
- Roll paper feeder allows continuous printing of multiple photos or panoramics on canvas and photo paper.
- Automatic print head cleaning and alignment utilities analyze your print quality and improve it quickly and easily.
- Hi-Speed USB 2.0 and FireWire® (IEEE 1394) ports provide fast connections.

Note: To achieve the highest USB speed, your computer must also have a Hi-Speed USB 2.0 port connected to the printer with a Hi-Speed USB 2.0 cable.

About Exif Print

The Exif (Exchangeable Image File) Print format includes information about your digital camera settings in JPEG/TIFF files so your printer and application can use them to create accurate print settings. Most digital cameras store Exif Print information such as shutter speed, metering, flash, and exposure settings, resolution, and lens use in the JPEG/TIFF image file. Your printer uses the information to ensure the most accurate image reproduction.

About Your Software

Your printer CD-ROM includes all the software you need for printing. See the *Start Here* sheet for installation instructions.

- **Your printer driver** runs your printer and lets you control how your documents look. You can't print without it.

Tip: It's a good idea to check Epson's support website periodically for free updates to your printer driver. Visit <http://support.epson.com>. Download instructions are posted for your convenience.

- **Your photo software** includes these great tools:

Epson EasyPrint Module (for Windows®) works with certain photo printing applications to make printing on your Stylus Photo R2400 fast and easy.

Epson Premium ICC Color Profiles work with Adobe Photoshop and other ICC-aware applications to achieve more accurate color in your prints on various paper types. You can download additional profiles at <http://support.epson.com>.

Epson PhotoCenterSM is Epson's free photo-sharing web site where you can store, organize, and share your photos; print high-resolution photos straight from the web; and create free online postcards. Your printer software installer lets you add a link to Epson PhotoCenter on your desktop.

About Your Documentation

To set up your printer and install its software, see the *Start Here* sheet.

This book contains instructions on:

- Loading all types of paper
- Printing with Windows or Mac® OS X
- Maintaining the printer
- Troubleshooting

At the end of the book, you'll also find the system requirements, important safety information, and the product's warranty.

Please follow these guidelines throughout:

Warnings must be followed carefully to avoid bodily injury.

Cautions must be observed to avoid damage to your equipment.

Notes contain important information about your printer.

Tips contain hints for better printing.


For more details about your printer, network setup instructions and specifications, see your on-screen *Reference Guide*, as described in the next section.

Viewing the On-screen Reference Guide

Follow the instructions on the *Start Here* sheet to install the on-screen *Reference Guide*, if you haven't already.

Note: You need a browser—such as Microsoft® Internet Explorer 4.0 or later, Safari™ 1.0 or later, Mozilla® Firefox® 1.0 or later, or Netscape® Navigator® 3.0 or later—to view the manual. If you are using a different browser, the pages may not display correctly.

1. Double-click the **SPR2400 Reference Guide** icon on your desktop.
2. Click a topic on the left to expand the table of contents.
3. Click the topic you want to view.
 - If there's a right arrow , click it to view subtopics, then click on a topic.
 - If there's a down arrow , click it to close a subtopic list.



Note: If you see an icon for an unloaded graphic when viewing your *Reference Guide* in Netscape Navigator, click the **Reload** button to load the graphic.

Loading Paper

You can load a variety of paper types in your printer, as described in these sections:


Paper/Media	Where to load	See page
Plain paper Epson Premium Photo Paper Glossy Epson Premium Glossy Photo Paper Epson Ultra Premium Photo Paper Luster Epson Premium Luster Photo Paper Epson Premium Photo Paper Semi-gloss Epson Premium Semigloss Photo Paper Epson Presentation Paper Matte Epson Photo Quality Ink Jet Paper Epson Premium Presentation Paper Matte* Epson Matte Paper Heavyweight* Epson Premium Presentation Paper Double-sided* Epson Double-sided Matte Paper* Epson Ultra Premium Presentation Paper Matte* Epson Enhanced Matte Paper* Epson Proofing Paper Semimatte Epson Bright White Paper Epson Premium Bright White Paper Epson Photo Quality Self Adhesive Sheets	Sheet feeder	12, 14
Epson UltraSmooth® Fine Art Paper PremierArt™ Matte Scrapbook Photo Paper for Epson Epson Velvet Fine Art Paper Epson Watercolor Paper - Radiant White	Single sheet guide	17

Roll paper, including PremierArt Water Resistant Canvas and Piezo Pro® Matte Canvas	Roll paper holder	21
Thick media or posterboard (1.0 - 1.3 mm thickness)	Front path	25


* This matte paper requires the matte sheet support when loading multiple sheets larger than letter-size; smaller paper can be loaded without it. See page 15 for instructions.

Loading Paper in the Sheet Feeder


1. Open the paper support and pull up the support extensions.



2. Push in the bottom of the output tray. The tray opens and moves up.



3. Pull out the output tray extension.
4. Place your paper in the printer and slide it against the right side of the sheet feeder.



Check the following as you load paper:

- Always load the short edge first, even for printing landscape-oriented documents.
 - Load the printable side face-up. It's usually whiter or brighter than the other side.
 - Load letterhead or preprinted paper into the printer top edge first.
 - Don't load paper above the arrow on the left edge guide.
5. Adjust the left edge guide to fit lightly against the paper.

Note: The left edge guide moves slightly during paper handling and printing. Do not adjust the guide during printing.

Loading Special Paper in the Sheet Feeder

You can load these Epson inkjet papers in the sheet feeder as follows:

Paper type	Loading capacity
Epson Premium Photo Paper Glossy Epson Premium Glossy Photo Paper Epson Premium Photo Paper Luster Epson Premium Luster Photo Paper Epson Premium Photo Paper Semi-gloss Epson Premium Semigloss Photo Paper Epson Premium Presentation Paper Matte* Epson Matte Paper Heavyweight* Epson Premium Presentation Paper Matte Double-sided* Epson Double-sided Matte Paper* Epson Ultra Premium Presentation Paper Matte* Epson Enhanced Matte Paper*	20 sheets (10 sheets for A3 or Super B sizes)
Epson Presentation Paper Matte Epson Photo Quality Ink Jet Paper	100 sheets (50 sheets for A3 or Super B sizes)
Epson Bright White Paper Epson Premium Bright White Paper	80 sheets
Epson Photo Quality Self Adhesive Sheets	1 sheet at a time

* This matte paper requires the matte sheet support when loading multiple sheets larger than letter-size; smaller paper can be loaded without it. See page 15 for instructions.

Check the paper package for additional handling instructions.


Note: Always keep unused paper in the original package and store it flat to prevent curling.

Loading Multiple Sheets of Matte Paper


If you are loading multiple sheets of the following papers in sizes larger than letter (8.5 × 11 inches), attach the matte sheet support to the top of the sheet feeder to help separate the sheets of paper and prevent misfeeds:

- Epson Ultra Premium Presentation Paper Matte
- Epson Enhanced Matte Paper
- Epson Premium Presentation Paper Matte
- Epson Matte Paper Heavyweight

1. Open the paper support and pull up its extensions.



2. Place the hook on the back of the matte sheet support over the paper support extension, and hold the top extension with one hand while sliding the matte sheet support all the way down.




3. Load your paper as described on page 12.

Note: Remove the matte sheet support when you load other types of paper.


Loading Special Paper in the Single Sheet Guide

Load these types of paper in the single sheet guide:


- Epson Watercolor Paper - Radiant White
 - Epson Velvet Fine Art Paper
 - Epson UltraSmooth Fine Art Paper
 - PremierArt Matte Scrapbook Photo Paper for Epson
1. Remove the roll paper holder if it's installed (see page 21).
 2. Slide the roll paper edge guide all the way to the right.




3. Line up the notches on the single sheet guide with the slots on the back of the printer and insert them as shown. Then insert the tabs on the top of the guide into the slot beneath the printer cover.




4. Turn on the printer (the printer must be on to load paper in the single sheet guide correctly).
5. Insert one sheet of paper against the right edge, then slide the left edge guide against the sheet.




6. Guide the paper into the slot and feed it into the printer until the paper meets resistance.




7. Maintain constant pressure against the paper until the printer pulls it in slightly. Continue to apply light pressure until the paper begins feeding, then let go of the paper to allow the printer to adjust the paper position.



8. Open the printer cover and look down into the printer to make sure the paper is loaded correctly. It should be straight and the leading edge of the paper should not be visible.



Paper is loaded correctly



If edge is visible, reload paper

If the paper isn't loaded correctly, press the  roll paper button for 3 seconds to back the paper out. Remove the paper, then press the  paper button to clear the paper out error. Reload the paper.

9. Before printing, select **Manual - Roll** as the Source setting (Windows) or **Manual - Roll** as the paper source setting within the Paper Size menu (Macintosh®) in your printer software (see page 28 for Windows or page 33 for Macintosh).


Loading Roll Paper or Canvas

You can load 4-inch, 8.3-inch, or 13-inch wide roll paper or 8.3-inch canvas for printing multiple photos or panoramas, with or without borders.

Note: Instructions apply to both roll paper and canvas unless otherwise noted.


Tip: It's a good idea to check your ink levels before loading and printing on roll paper (see page 83). If you need to replace a cartridge with roll paper loaded, you should remove the paper or marks may appear in your printout.

1. Turn on the printer and remove any paper loaded in the sheet feeder.
2. Close the paper support at the top of the printer.
3. If the output tray and extension are open, push them in, but leave the flap at the end of the tray down.
4. Swing out the roll paper guides until they are straight.



Tip: Use lint-free, white cotton gloves when handling the media to avoid soiling it with the oils on your fingertips.


5. Place the roll paper on the holders as shown, then remove the tape and protective paper from the end of the roll.



6. Make sure the end of the paper is cut straight across, with 90° corners. If the end is cut diagonally, you may have problems feeding the paper.


If you're loading canvas, it is important to cut the edge so it's straight and even.

7. If the paper curls at the end, roll it backwards between a folded sheet of paper to uncurl it.




Avoid touching the printable surface of the roll paper with your hands.

8. Insert the left roll paper holder (marked with an orange triangle) into the far left slot (also marked with an orange triangle). Then insert the other holder into the corresponding slot on the right.



9. While holding the paper, feed it part of the way into the roll paper feeder (under the white rollers), then slide the right roll paper edge guide to fit lightly against the paper.



Caution: Don't load roll paper into the sheet feeder or the slot behind the paper support; make sure it is loaded below the white rollers.


10. Push the paper into the feeder until it meets resistance. Maintain pressure on the paper until the printer feeds the paper automatically.

Note: You may need to reload canvas or thicker roll media to ensure accurate paper registration.


When loading canvas, leave ample slack between the roll and the printer to ensure smooth paper feeding. Be sure to maintain slack while printing. If you don't, your prints may show distortion of shapes, fuzzy text, or banding.

When cutting canvas or other roll paper, it is important to have a straight edge. An uneven or frayed edge may result in misfeeds, misregistration, or unacceptable print quality.

11. Open the printer cover and look down into the printer to make sure the paper is loaded correctly. It should be straight and the leading edge of the paper should not be visible.



Paper is loaded correctly



If edge is visible, reload paper

If the paper isn't loaded correctly, press the  roll paper button for 3 seconds to back the paper all the way out.

Then turn the roll paper holder knobs to roll up the paper. Press the  paper button to clear the paper out error. Repeat steps 7 through 9 to reload the paper.


Follow the instructions on page 43 to print on roll paper.

Loading Thick Media in the Front Path

You can load media 1.0 to 1.3 mm thick into the front path, in sizes from 8 × 10 inches to A3+.


Note: Since the media feeds through the printer from the front to the rear, make sure there is enough space behind the printer for the media to move completely through the printer.

1. Turn on the printer and remove any paper loaded in the sheet feeder at the top of the printer.
2. Close the paper support at the top of the printer.
3. If the output tray and extension are open, push them in, but leave the flap at the end of the tray down.
4. Open the printer cover. Then open the front path door completely by pressing the front path door release area.



5. Close the printer cover.

6. Insert the media two or three inches into the printer, and push the left edge guide against the media's edge. Maintain slight pressure on the guide while inserting the media the rest of the way into the printer. Stop when the front edge of the media is aligned with the arrow on the right side.



7. Press the  paper button. The media is fed into the printer automatically. When the  power light stops flashing, the printer is ready to print. (To remove the thick media without printing, press the  paper button again.)
8. Before printing, select **Manual - Front** as the Source setting (Windows) or **Manual - Front** as the paper source setting within the Paper Size menu (Macintosh) in your printer software (see page 28 for Windows or page 33 for Macintosh).

Note: If the printer fails to load the media and displays an error, remove the media and turn off the printer. Then turn the printer on again.

Printing From Start to Finish

Follow the steps in these sections to print using your printer's basic features:

- “Basic Printing in Windows” on page 28
- “Customizing Your Windows Print Settings” on page 31
- “Basic Printing With Mac OS X” on page 33
- “Customizing Your Macintosh Print Settings” on page 39
- “Selecting the Correct Paper Type” on page 41

To print on roll paper or borderless cut sheets, or color-managed photos, see “Printing Special Photos” beginning on page 43.

Note: During printing, the left edge guide moves away from the paper slightly. Do not adjust it while the printer is printing. The printer will re-adjust the edge guide when printing is complete.

Tip: Whenever you print, make sure you:


- **Use the right paper.**
For the best-looking photos, most vivid colors, and greatest detail, always use genuine Epson papers and Epson UltraChrome K3 inks.
- **Choose the right printer settings for the paper.**
Your printer automatically adjusts itself for the type of paper you've selected, so make sure your printer settings are correct for the paper you loaded.

Basic Printing in Windows

Follow the steps below to print a document or image using the basic printer settings.

For roll paper printing, see page 43. For borderless printing, see page 49.

1. From the File menu, click **Print**. You see a Print window like this one:



Check for your printer name here

Click here to open your printer software


2. Make sure **EPSON Stylus Photo R2400** is selected.
3. Click the **Properties** or **Preferences** button. (If you see a **Setup**, **Printer**, or **Options** button, click it first.)
4. Click the **Main** tab in the printer settings window to see your basic settings.

Select the type of document you're printing

Select your paper source

Select your paper type (see page 41)

Select your paper size



Select your print options

Select your document or image orientation

5. Select one of these document types as the Quality Option setting:
 - **Draft:** For rough drafts with reduced print quality
 - **Text:** For text-only documents (like letters) with good print quality
 - **Text & Image:** For documents with text and images with higher print quality
 - **Photo:** For photos and graphics with good print quality and speed
 - **Best Photo:** For photos or graphics with high print quality
6. Select the way your paper is loaded as the Source setting:
 - **Sheet:** For paper loaded in the sheet feeder at the top of the printer
 - **Roll:** For roll paper loaded in the roll paper feeder on the back of the printer (see page 43)
 - **Manual - Roll:** For paper loaded in the single sheet guide
 - **Manual - Front:** For poster and matte boards loaded in the front path (see page 25)
7. Select the type of paper you loaded as the Type setting. See page 41 for details.

Note: The media types listed will vary depending upon the type of black ink cartridge currently installed. See page 68 for details.


For printing photos without borders on certain paper types, click the **Borderless** checkbox. See page 49 for details.
8. Select the size of paper you loaded as the Size setting.
9. Select the direction in which you want your image or document to print as the Orientation setting. Select **Portrait** for vertical orientation or **Landscape** for horizontal.
10. Select any other options you want to use in the Print Options box:
 - **PhotoEnhance™:** Improves the contrast, saturation, and color balance of low-resolution photos (affects only your printout)
 - **Reverse Order:** Prints multiple page documents last-page-first so you don't need to reorder the pages
 - **Print Preview:** Displays a preview of your printed image or document before printing so you can check its position on the page

Note: For more information about printer settings, click the ? or **Help** button. For additional print settings, click the **Advanced** button at the bottom of the screen and see page 31 for details.

11. Click **OK** to return to the Print window.

12. Click **OK** or **Print** to start printing.

During printing, this window appears. Use it to cancel, pause, or resume printing and check ink cartridge status.



Caution: Don't open Epson Status Monitor, pause printing, or respond to ink messages when your printer is printing. This may cause your printer to pause and leave an uneven surface on your printout. If ink is low, wait until printing finishes before checking ink levels or replacing a cartridge. If you replace an ink cartridge in the middle of a print job, the quality of your printout may decline. For best results, check ink levels and replace cartridges, if necessary, before printing large or high-resolution print jobs.

Selecting the Settings You Use Most Often

Your printer settings apply only to the program you're currently using. If you want, you can change the Windows default printer settings for all your programs.


1. Right-click the  printer icon in the lower right corner of your screen.
2. Select **Printer Settings**. You see the window shown on page 28.
3. Select the default settings you want for all your applications, then click **OK**.

You can still change the printer settings in individual programs, if necessary.

Customizing Your Windows Print Settings

Follow these steps to print a document or image using advanced printer settings:

1. On the Main tab, click the **Advanced** button in the bottom right corner.
2. Click **Continue**. The Basic settings change to the Advanced settings:



Note: If you want to use the Advanced screen each time you access your printer settings, select the **Show this screen first** checkbox.

3. The Advanced settings include the same options as the Basic settings, plus these:
 - **Print quality:** Lets you specify a print quality for your selected paper type, including **Photo** (1440 × 720), **Best Photo** (1440 × 1440), and **Photo RPM®** (5760 × 1440 dpi) for the highest print quality on certain paper types. (Printing takes longer in this mode.)
 - **High Speed:** Speeds up printing by allowing printing back and forth across the page, instead of in just one direction. (Print quality may decrease.)

- **Edge Smoothing:** Prints smoother edges on low-resolution images, such as bars in a graph.
- **Color Controls:** Lets you adjust the Brightness, Contrast, Saturation, and cyan, magenta, and yellow levels in your printout.
- **Advanced B&W Photo:** Lets you access Color Toning, Toning, and other image adjustments when printing black and white images. Choose a preset Color Toning with the menu or create a custom setting by clicking **Settings**. See “Advanced Black and White Photo Printing” on page 73 for more details.

Note: The availability of the Advanced B&W Photo setting depends on the ink cartridge installed (Photo Black or Matte Black), the Paper Type setting, and the print quality setting.

- **ICM:** Uses standard color profiles for your printer to help match colors in your image, for use with certain ICM-enabled applications. If you’re using custom or Epson Premium ICC profiles in a program such as Photoshop, select **ICM** and then check the **Off (No Color Adjustment)** box.


Caution: Incorrectly applying this function or using it in an incomplete color management workflow may result in excessively light or dark prints.

Note: To print with custom or Premium ICC color profiles using Photoshop, see “Managing Color With Profiles” on page 53.

4. Once you’ve finished selecting advanced settings, you can:

- Click **OK** to save your settings, return to the Print dialog box, and print.
- Click the **Basic** button to return to the Basic settings.
- Click the **Page Layout** tab and continue with step 5 to select layout options.

5. Select the following page layout settings as necessary:



Note: For more information on printer settings, or instructions on saving them as a group so you can reuse them later, click the **Help** or ? button.

6. Click **OK** to save your settings, return to the Print dialog box, and print.

Basic Printing With Mac OS X


Follow the steps below to print a document or image on a Macintosh using the basic printer settings.

For roll paper printing, see page 43. For borderless printing, see page 49.

Note: Make sure you added your printer in the Printer Setup Utility or Print Center, as described on the *Start Here* sheet.

1. From the File menu, select **Page Setup**.

2. Open the Format for menu and select your printer.



3. Open the Paper Size menu and select the size of the paper you loaded. Then select the source setting from the submenu for that size.




- For prints on paper loaded in the sheet feeder with borders around the image, select just a paper size in the menu or submenu.
- For borderless prints on paper loaded in the sheet feeder, select a size with **Sheet Feeder - Borderless** as the source.
- For prints with borders around the image on paper loaded in the single sheet guide, select a size with **Manual - Roll** as the source.
- For borderless prints on paper loaded in the single sheet guide, select a size with **Manual - Roll(Borderless)** as the source.

- For prints made on thick media loaded into the front path, choose **Manual - Front** as the source.

For roll paper printing instructions, see page 43. For details on borderless printing, see page 49.

Caution: When printing non-borderless print jobs using a custom paper size, make sure the selected size matches the paper you loaded and is within the printable area for your printer. For example, never choose a paper size wider than your printer's sheet feeder or longer than your paper length. The maximum width for custom paper sizes is 12.95 inches.


4. Select the direction you want your image or document to print as the Orientation setting. Select  for vertical orientation,  for horizontal facing left, or  for horizontal facing right.
5. Click OK.
6. Select **Print** from the File menu. You see a screen like this:



7. Open the **Printer** menu and select **Stylus Photo R2400**.
8. Select **Print Settings** from the pop-up menu.

Note: In certain programs you may need to select **Advanced** before you can select **Print Settings**.

You see your basic print settings:



9. Select the type of paper you loaded as the Media Type setting; see page 41.

Note: If you don't see the paper type you want to use, check your Page Setup settings to make sure you selected the correct paper size and source; see page 34, or that you have the correct black ink cartridge installed; see page 68.

10. For the color setting, select **Color** (for color documents and black and white photographs), or **Advanced B&W Photo** (for accessing Color Toning and other image adjustments when printing black and white photographs; see page 73), or **Black** (for black text documents).

Note: The availability of the Advanced B&W Photo setting depends on the ink cartridge installed (Photo Black or Matte Black), the Media Type setting, and the print quality setting.

11. Select **Automatic** as the Mode setting for the best results printing basic documents or images. (For instructions on using Advanced mode, see page 39.)
12. If available, move the slider to the **Quality** setting to print images or documents using higher print quality, or to the **Speed** setting for faster printing.

Note: For more information about printer settings, click ?.


13. You can also choose these options in the pop-up menu:

- **Copies & Pages**, to select the number of copies or a page range
- **Layout**, to select page layout options
- **Output Options**, to save your print job as a PDF file
- **Scheduler**, to specify a time for a document to print
- **Paper Handling**, to reverse page order and set other page options
- **ColorSync**, to select Quartz® filters through ColorSync®
- **Color Management**, to select ColorSync (for use with certain ColorSync-enabled applications), adjust the color controls, change the gamma setting, or turn off color adjustments by the printer software (see page 40 for color management details)
- **Expansion** (if you selected a **Borderless** option as the paper size/source setting), adjusts the image size to remove borders completely
- **Extension Setting**, select **Thick paper** to correct ink smearing when printing on thick paper
- **Summary**, to view a list of all your selections

14. Click **Print**.

Caution: Don't open Epson Status Monitor, pause printing, or respond to ink messages when your printer is printing. This may cause your printer to pause and leave an uneven surface on your printout. If ink is low, wait until printing finishes before checking ink levels or replacing a cartridge. If you replace an ink cartridge in the middle of a print job, the quality of your printout may decline. For best results, check ink levels and replace cartridges, if necessary, before printing large or high-resolution print jobs.

15. To monitor the progress of your print job, click your printer's  icon or the  Print Center icon when it appears in the dock. Then double-click **Stylus Photo R2400**. You see this screen:



16. Monitor the progress of your print job or do one of the following:
- Click the print job, then click **Delete** to delete the job
 - Click the print job, then click **Hold** to pause printing
 - Click a print job marked “Hold” and click **Resume** to resume printing
 - If multiple print jobs are listed, click a print job, then click the **Priority** arrow as necessary to reorder the jobs
17. When you're finished, close your printer's status window (OS X 10.3 and 10.4) or Print Center (OS X 10.2).


Customizing Your Macintosh Print Settings

Follow these steps to print a document or image using advanced printer settings:

1. From the File menu, select **Print**.
2. Select **Print Settings** from the pop-up menu.

Note: In certain programs you may need to select **Advanced** before you can select **Print Settings**.

3. To access advanced settings, click **Advanced**.



4. In addition to the basic settings, you can select these advanced options:
 - **Print Quality:** Lets you specify a print quality for your selected paper type, including **Photo** (1440 × 720), **Best Photo** (1440 × 1440), and **Photo RPM** (5760 × 1440 dpi) for the highest print quality on certain paper types. (Printing takes longer in this mode.)
 - **High Speed:** Speeds up printing by allowing printing back and forth across the page, instead of in just one direction. (Print quality may decrease.)

- **Mirror Image:** Inverts the image horizontally.
- **Finest Detail:** Places ink droplets in the most precise manner for high quality printing. (Printing takes longer in this mode.)

Note: For more information on printer settings, click ?.

5. To select Color Management options, select **Color Management** from the pop-up menu. Select Color Management options as follows:
 - **Color Controls:** Lets you adjust the Brightness, Contrast, Saturation, Gamma, and cyan, magenta, and yellow levels in your printout. (Click the **Advanced Settings** arrow to access these adjustments.)
 - **ColorSync:** Uses standard ColorSync profiles for your printer to help match colors in your image, for use with certain ColorSync-enabled applications. If you're using custom or Epson Premium ICC profiles in a program such as Photoshop, select **Off (No Color Adjustment)** instead.
 - **Off (No Color Adjustment):** Turns off your printer's color management features so you can use ICC profiles in an ICC-aware application such as Adobe Photoshop instead.

Caution: Incorrectly applying this function or using it in an incomplete color management workflow may result in excessively light or dark prints.

Note: To print with custom or Premium ICC color profiles using Photoshop, see "Managing Color With Profiles" on page 53.

6. Click **Print**.

Selecting the Correct Paper Type

Select the correct **Type** or **Media Type** setting so your printer knows what kind of paper you're using and adjusts the ink coverage accordingly. Certain paper types may be unavailable depending on which black ink cartridge is installed. See "Matching Black Ink to Paper Type" on page 68.

Paper loaded	Type or Media Type setting
Plain paper sheets Epson Bright White Paper Epson Premium Bright White Paper	Plain Paper
Epson Presentation Paper Matte Epson Photo Quality Ink Jet Paper Epson Photo Quality Self Adhesive Sheets	Presentation Paper Matte
Epson Ultra Premium Presentation Paper Matte Epson Enhanced Matte Paper	Ultra Premium Presentation Matte
Epson Premium Presentation Paper Matte Epson Matte Paper Heavyweight Piezo Pro Matte Canvas for Epson*	Premium Presentation Paper Matte
Epson Premium Presentation Paper Matte Double-sided Epson Double-sided Matte Paper	Double-sided Matte Paper
Epson Premium Photo Paper Glossy Epson Premium Glossy Photo Paper	Premium Photo Paper Glossy
Epson Ultra Premium Photo Paper Luster Epson Premium Luster Photo Paper PremierArt Water Resistant Canvas for Epson*	Ultra Premium Photo Paper Luster
Epson Premium Photo Paper Semi-gloss Epson Premium Semigloss Photo Paper	Premium Photo Paper Semi-Gloss
Epson Watercolor Paper - Radiant White	Watercolor Paper - Radiant White
Epson UltraSmooth Fine Art Paper (325) PremierArt Matte Scrapbook Photo Paper for Epson	UltraSmooth Fine Art Paper
Epson Velvet Fine Art Paper	Velvet Fine Art Paper

* These papers are optimized for use with premium ICC profiles. See page 53 for details.

Printing Special Photos

When you need to print photos using the special Stylus Photo R2400 printing features, follow the instructions in these sections:

- “Printing on Roll Paper” below
- “Printing Borderless Cut Sheets” on page 49
- “Managing Color With Profiles” on page 53
- “Easy Printing With Photoshop Elements 3.0” on page 67
- “Matching Black Ink to Paper Type” on page 68
- “Advanced Black and White Photo Printing” on page 73

Printing on Roll Paper

Before you print on roll paper, load the paper as described on page 21.

Then follow the steps in the next sections to select your roll paper settings, control printing, and remove and store roll paper.

Caution: Don’t open Epson Status Monitor, pause printing, or respond to ink messages when your printer is printing. This may cause your printer to pause and leave an uneven surface on your printout. If ink is low, wait until printing finishes before checking ink levels or replacing a cartridge. If you replace an ink cartridge in the middle of a print job, the quality of your printout may decline. For best results, check ink levels and replace cartridges, if necessary, before printing large or high-resolution print jobs.

Selecting Roll Paper Print Settings

Follow the steps in one of these sections to select your roll paper print settings:

- “Windows” below
- “Mac OS X” on page 45

Windows

1. Start your print application, open your photo file, and resize it as necessary.
2. Open the File menu, click **Print**, then click **Properties** or **Preferences**.
3. Select the type of roll paper you loaded as the Type setting:

- **Premium Photo Paper Semi-Gloss**
- **Ultra Premium Photo Paper Luster**
- **Premium Photo Paper Glossy**

Note: For PremierArt Water Resistant Canvas, choose **Ultra Premium Photo Paper Luster**. For Piezo Pro Matte Canvas, choose **Premium Presentation Paper Matte**. When printing on canvas, choose **Best Photo** or **Photo RPM** and turn **High Speed** off. For the best color prints on either Epson canvas medium, be sure to use the Premium ICC Profile.




4. If you'll be printing photos without any borders, click the **Borderless** box.
5. Select the photo size as the Size setting.

If you're printing a panoramic photo, select **User Defined** from the Size list and enter the size of your photo. Make sure the width of your photo is 4, 8.3, or 12.95 inches maximum, depending on the width of the roll paper you loaded. Also set the margins to **0** in your printing software.

Note: Don't select PhotoEnhance when printing on roll paper. For the Source setting, don't choose **Sheet** or **Manual - Roll**.

- Choose **Roll** as the Source setting. The Roll Paper Options dialog box pops up:
- Select the roll paper settings, including whether to print a page frame, based on the type of printing you're doing (see the table below); then click **OK**:




Type of printing	Roll Paper Options
Borderless photos	Cut Sheet Mode or Banner Mode (if your photo is over 27 inches long)
Photos with borders or panoramics	Cut Sheet Mode

- Click **OK**.
- Click **OK** or **Print**.

Follow the steps on page 48 to remove your printed photos.

Mac OS X

- Start your print application, open your photo file, and resize it as necessary.
- From the File menu, select **Page Setup**.
- Open the Format for menu and select your printer:



Select Stylus Photo R2400

Select the size and roll paper setting for the photo you're printing


4. Open the Paper Size menu and select your photo size. Then select a **Roll Paper** or **Roll Paper - Borderless** setting from the submenu for that size.

To print without a border between photos, choose a **Roll Paper - Borderless Banner** setting for your photo size.

Make sure the width of your photo is 4, 8.3, or 13 inches maximum, depending on the width of the roll paper you loaded. Also set the margins to 0 in your printing software.

5. Click **OK**.
6. Select **Print** from the File menu.
7. Open the Printer menu and select **Stylus Photo R2400**.
8. Select **Print Settings** from the pop-up menu.


Note: In certain programs you may need to select **Advanced** before you can select **Print Settings**.



9. Select the type of roll paper you loaded as the Media Type setting:
- Premium Photo Paper Semi-Gloss
 - Ultra Premium Photo Paper Luster
 - Premium Photo Paper Glossy

Note: For PremierArt Water Resistant Canvas, choose **Ultra Premium Photo Paper Luster**. For Piezo Pro Matte Canvas, choose **Premium Presentation Paper Matte**. When printing on canvas, choose **Best Photo** or **Photo RPM** and turn **High Speed** off. For the best color prints on either Epson canvas medium, be sure to use the Premium ICC Profile.

10. Move the slider to the **Quality** setting (if available).
11. Choose **Roll Paper Option** from the pop-up menu.



12. Select the roll paper settings, including whether to include a page frame, based on the type of printing you're doing.


Type of printing	Roll Paper Options
Borderless photos	Cut Sheet Mode Banner Mode (if your photo is over 27 inches long)
Photos with borders or panoramics	Cut Sheet Mode

13. Click **Print**.

Removing Your Printed Photos

Follow these steps to remove your printed photos:



1. Press the  roll paper button once to feed the paper forward.
2. Cut the paper on the printed cutting line.
3. If you want to print another job on roll paper, press the  roll paper button once again; the paper returns to the correct print position.



Removing and Storing Roll Paper

Follow these steps when you're ready to remove and store your roll paper:

1. Press the  roll paper button for 3 seconds. The paper feeds backwards out of the printer. (If it doesn't feed all the way out, repeat this step.)



2. Turn the knobs to roll the rest of the paper onto the holder. Then press the  paper button to turn off the  paper light.
3. Pull the roll paper holder off the printer and remove the roll paper from it.

Return the unused roll to its original package. Store your printouts in resealable plastic bags, photo albums, or glass-covered picture frames. Keep both printed and unused roll paper away from high temperatures, humidity, and direct sunlight.

Printing Borderless Cut Sheets

You can print your photos with no margins, extending the image all the way to the edges of the page. Although borderless printing is a bit slower, you get beautiful portraits and enlargements, without trimming, on these papers:

- Epson Premium Photo Paper Glossy or
Epson Ultra Premium Glossy Photo Paper
- Epson Premium Presentation Paper Matte* or
Epson Matte Paper Heavyweight*
- Epson Ultra Premium Presentation Paper Matte* or
Epson Enhanced Matte Paper*
- Epson Premium Presentation Paper Matte Double-sided* or
Epson Double-Sided Matte Paper *
- Epson Ultra Premium Photo Paper Luster
Epson Premium Luster Photo Paper
- Epson Premium Photo Paper Semi-gloss
Epson Premium Semigloss Photo Paper
- Epson Watercolor Paper - Radiant White**
- Epson Velvet Fine Art Paper**
- Epson UltraSmooth Fine Art Paper**
- PremierArt Matte Scrapbook Photo Paper for Epson**

* If you are loading multiple sheets of matte paper that are larger than letter-size, use the matte sheet support. See page 15.

** These papers must be loaded in the single sheet guide. See page 17.

Caution: Don't open Epson Status Monitor, pause printing, or respond to ink messages when your printer is printing. This may cause the printer to pause and leave an uneven surface on your printout. If ink is low, wait until printing finishes before checking ink levels or replacing a cartridge. If you replace an ink cartridge in the middle of a print job, the quality of your printout may decline. For best results, check ink levels and replace cartridges, if necessary, before printing large or high-resolution print jobs.

Follow the steps in one of these sections to print BorderFree photos on cut sheet paper:

- “Windows” below
- “Mac OS X” on page 51


Windows

1. Start your print application and open your photo file.
2. Open the File menu, click **Print**, then click **Properties** or **Preferences**.
3. Select **Photo** or **Best Photo** as the Quality Option.
4. Choose **Sheet** as the Source setting.
5. Select the type of paper you loaded as the Type setting. See page 41 for details.
6. Click the **Borderless** checkbox.
7. Select your paper size as the Size setting.
8. Select **Portrait** or **Landscape** as the orientation setting.
9. Click the **Page Layout** tab, then adjust the **Expansion** setting. Choose **Min** for the least amount of image expansion (with a chance that there may be small borders around the edges) or **Max** for the greatest amount of expansion (some of the image will be cut off around the edges, but it will extend to the edge of the paper).
10. Click **OK**.
11. Click **OK** or **Print**.



Mac OS X


1. Start your print application and open your photo file.
2. From the File menu, select **Page Setup**.
3. Open the Format menu and select your printer.



4. Open the Paper Size menu and select the paper size for the paper you loaded. Then select a **Sheet Feeder - Borderless** setting from the submenu.
5. Select one of the portrait or landscape orientation icons as the Orientation setting.
6. Click OK.
7. Select **Print** from the File menu.
8. Open the Printer menu and select **Stylus Photo R2400**.

9. Select **Print Settings** from the pop-up menu.

Note: In certain programs you may need to select **Advanced** before you can select **Print Settings**.



10. Select the type of paper you loaded as the Media Type setting. See page 41 for details.

Note: If you can't choose your paper type, check the Paper Size settings on the Page Setup window to make sure you selected the correct paper size and source, or that you have the correct black ink cartridge installed (see page 70 for information).

11. Move the slider to the **Quality** setting.
12. Choose **Expansion** from the pop-up menu, then adjust the Expansion setting. Choose **Min** for the least amount of image expansion (with a chance that there may be small borders around the edges) or **Max** for the greatest amount of expansion (some of the image will be cut off around the edges, but it will extend to the edge of the paper).
13. Click **Print**.

Managing Color With Profiles

Follow the steps in this section to use color profiles for printing with Adobe Photoshop (the instructions cover Photoshop 7, CS, CS2, and CS3).

Carefully follow the instructions in these sections for the best results:

- “Printing With a Color Profile” below
- “Solving Color Management Problems” on page 62
- “Printing a Custom Profile Test Target” on page 62
- “Creating a Custom Profile” on page 66

Printing With a Color Profile


To print an image using a profile, follow the steps in one of these sections.

- “Windows” below
- “Mac OS X” on page 58


Windows

Opening Your Image


1. Open Adobe Photoshop.
2. Select **Edit > Color Settings**.
3. Select **U.S. Prepress Defaults** or **North America Prepress 2** from the Settings pull-down menu. This sets **Adobe RGB (1998)** as the RGB working space and activates warning messages for profile mismatches and missing profiles. Click **OK**.
4. Open the photo you want to print.



5. If you see this message, select **Use the embedded profile (instead of the working space)** and click **OK**. It is generally best to use the embedded profile.



6. If you see this message, select **Assign working RGB: Adobe RGB (1998)** and click **OK**:



7. When your image appears, evaluate the color balance and contrast as displayed on your monitor. If they need improvement, select **Image > Mode > Assign Profile** (for Photoshop CS and 7) or **Edit > Assign Profile** (for Photoshop CS2 and CS3). Select one of the following as the Profile setting:

- A different RGB working space, such as **ColorMatch RGB** or **sRGB IEC61966-2.1**
- A scanner profile for your scanner
- A camera profile for your digital camera

Also click the **Preview** box so you can see the effects of your profile choice on the screen.


Tip: This is most effective when your monitor is calibrated using a hardware device such as the X-Rite® Eye-One® Display 2 or Color vision® Spyder2.™

8. Click **OK**.

Note: Assigning a profile to the image doesn't alter the image data, only the interpretation of the data by your software and how it appears on your monitor and in a printout. This is the best way to improve the color balance and contrast in your image.


Selecting Your Print Settings

1. Select File > Page Setup.
2. Select the Size for your paper and the correct Orientation for your image:




3. Click OK.
4. Select File > Print or Print with Preview.
5. If necessary, click More Options or Show More Options. If you see Output, select Color Management from the pull-down menu.

Additional options appear:



Photoshop 7, CS



Photoshop CS3

6. Under Color Handling in Photoshop CS2, select **Let Photoshop Determine Colors**. In CS3, select **Photoshop Manages Colors**.
7. Under Profile or Printer Profile, select the Epson Premium ICC profile that matches your printer, the paper you'll use for the print, and the quality setting.

Note: The Epson Premium ICC profiles can be identified with the suffix ".icc," for example, "SPR2400 PremLuster BstPhoto.icc."

8. For the Intent or Rendering Intent setting, select **Relative Colorimetric**.

Note: If your image contains very saturated colors, select **Perceptual** instead. This reduces the color saturation so that the colors fit within the printer's color gamut.

9. Select the **Use Black Point Compensation** checkbox.


Printing Your Color-Managed Photo

1. Click the **Print** button.
2. Make sure your printer is selected, and click the **Properties** or **Preferences** button.
3. If you are using an Epson Premium ICC profile, set the **Quality Option** setting to match your profile.
4. Select the **Type** setting for the paper you'll use for the print.

Note: For printouts on PremierArt Water Resistant Canvas, select **Ultra Premium Photo Paper Luster** for the paper type setting. For printouts on Piezo Pro Matte Canvas, select **Premium Presentation Paper Matte**. Additionally, make sure the Photo Black ink cartridge is installed. See "Matching Black Ink to Paper Type" on page 68.

5. Click the **Advanced** button, then click **Continue**.
6. Turn *off* the **High Speed** and **Edge Smoothing** settings, if they are available.

- Click the ICM button under Color Management, then Select Off (No Color Adjustment).



IMPORTANT!
Select Off (No Color Adjustment)



Note: Make sure that you select **Off (No Color Adjustment)**. If you don't, the printer driver will apply additional correction to the image data, producing inaccurate results.

- Click **OK**.
- Click **OK** or **Print** to print your photo.


Mac OS X

Opening Your Image

1. Open Adobe Photoshop.
2. Select **Color Settings** from the **Photoshop** menu (Photoshop 7 or CS) or the **Edit** menu (Photoshop CS2 or CS3).
3. Select **U.S. Prepress Defaults** or **North America Prepress 2** from the Settings pull-down menu. This sets **Adobe RGB (1998)** as the RGB working space and activates warning messages for profile mismatches and missing profiles. Click **OK**.
4. Open the photo you want to print.
5. If you see the message shown below, select **Use the embedded profile (instead of the working space)** and click **OK**. It is generally best to use the embedded profile.



6. If you see the message shown below, select **Assign working RGB: Adobe RGB (1998)** and click **OK**.



7. When your image appears, evaluate the color balance and contrast as displayed on your monitor. If they need improvement, select **Image > Mode > Assign Profile** (for Photoshop CS and 7) or **Edit > Assign Profile** (for Photoshop CS2 and CS3). Select one of the following as the Profile setting:

- A different RGB working space, such as **ColorMatch RGB** or **sRGB IEC61966-2.1**
- A scanner profile for your scanner
- A camera profile for your digital camera

Also click the **Preview** box so you can see the effects of your profile choice on the screen.


Tip: This is most effective when your monitor is calibrated using a hardware device such as the X-Rite Eye-One Display 2 or Color vision Spyder2.

8. Click **OK**.

Note: Assigning a profile to the image doesn't alter the image data, only the interpretation of the data by your software and how it appears on your monitor and in a printout. This is the best way to improve the color balance and contrast in your image.

Selecting Your Print Settings


1. Select **File > Print** or **Print with Preview**. If you see a window like this, click **More Options** or **Show More Options**.
2. Click the **Page Setup** button to change the page size and orientation settings as necessary, then click **OK**.



3. Click **Color Management** from the pop-up menu:



Photoshop 7, CS



Photoshop CS3

4. Under **Color Handling** in Photoshop CS2, select **Let Photoshop Determine Colors**. In CS3, select **Photoshop Manages Colors**.
5. Under **Profile** or **Printer Profile**, select a profile for your printer and the paper you'll use for the print. If you're printing with Epson Premium ICC profiles, select the profile that matches the print quality you want to use.

Note: The Epson Premium ICC profiles can be identified with the suffix ".icc," for example, "SPR2400 PmGlsy BstPhoto.icc."

6. For the **Intent** or **Rendering Intent** setting, select **Relative Colorimetric**.

Note: If your image contains very saturated colors, select **Perceptual**. This reduces the color saturation so that the colors fit within the printer's color gamut.

7. Select the **Black Point Compensation** checkbox.

Printing Your Color-Managed Photo


1. Click the **Print** button.
2. Select **Stylus Photo R2400** from the **Printer** menu.

3. Select **Print Settings** from the pop-up menu.

Note: In certain programs you may need to select **Advanced** before you can select **Print Settings**.


4. Select the **Media Type** setting for the paper you'll use for the print.

Note: For printouts on Epson PremierArt Water Resistant Canvas, select **Ultra Premium Photo Paper Luster** for the paper type setting. For printouts on Piezo Pro Matte Canvas, select **Premium Presentation Paper Matte**. Additionally, make sure the Photo Black ink cartridge is installed. See "Matching Black Ink to Paper Type" on page 68.



5. Click the **Advanced** button.
6. If you are using an Epson Premium ICC profile, set the **Print Quality** setting to match your profile.
7. Turn off the **High Speed** setting.
8. Select **Color Management** from the pop-up menu.
9. Select **Off (No Color Adjustment)**.

Note: Make sure that you select **Off (No Color Adjustment)**. If you don't, the printer driver will apply additional correction to the image data, producing inaccurate results.



IMPORTANT!
Select Off (No Color Adjustment)

10. Click **Print** to print your photo.

Solving Color Management Problems

If you selected the wrong combination of source profile, printer profile, and color management settings, you'll get unexpected results. Try these solutions:

- If your printed image is darker than expected and/or has a strong yellow-brown cast, you probably turned off color management in both Photoshop and the Epson printer driver.

Return to the Print or Print with Preview instructions for Adobe Photoshop on page 59 (for Mac OS X) or page 55 (for Windows). Make sure the Source Space - Document option is *not* set to **Untagged RGB**. Also make sure you selected the correct profile for your printer in the Print Space - Profile menu.

- If your printed image is lighter than expected and/or has a strong light blue cast, you probably turned on color management in both Photoshop and the Epson printer driver.

Return to the instructions on page 61 (for Mac OS X) or page 57 (for Windows). Make sure to select **Off (No Color Adjustment)** in the printer driver Advanced screen or Color Management menu to turn off color management in your Epson printer driver.


Printing a Custom Profile Test Target

Follow the steps in this section to create and print individual custom profile test targets for each paper type you plan to print on. For Mac OS X, see below. For Windows, see page 65.


Mac OS X

1. Open Adobe Photoshop and open the profile target file provided by your profile-building software manufacturer.
2. If you see a missing profile screen, select **Leave as is (don't color manage)**.
3. Select **File > Print with Preview**.
4. In the Print window, click **Show More Options**, then choose **Color Management** in the pop-up menu.

5. Select **No Color Management** (Photoshop CS2 or CS3) or **Same as Source** (Photoshop CS or 7) as the Print Space: Profile setting.




6. Click the **Page Setup** button. You see this window:



7. Select **Stylus Photo R2400** from the Format for menu.
8. Select the appropriate Paper Size and Orientation settings, then click **OK**.
9. Click the **Print** button.
10. Select your printer from the Printer menu, then select **Print Settings** from the pop-up menu.

Note: In certain programs you may need to select **Advanced** before you can select **Print Settings**.

11. Select the Media Type setting for the profile you're printing.



12. Click the **Advanced** button.

13. Select your desired level as the **Print Quality** setting.

14. Turn *off* the High Speed setting.

15. Select **Color Management** from the pop-up menu.

16. Select **Off (No Color Adjustment)**.

IMPORTANT!

Select Off (No Color Adjustment)




17. Click **Print** to print your test target.


18. Repeat these steps to print a test target for each paper type and Print Quality setting you plan to print with.

Windows

1. Open Adobe Photoshop and open the profile target file provided by your profile-building software manufacturer.
2. If you see a missing profile screen, select **Leave as is (don't color manage)**.
3. Select **File > Print** or **Print with Preview**.
4. In the Print window, click the **Show More Options** checkbox, then choose **Color Management** in the pull-down menu.
5. Select **No Color Management** (Photoshop CS2 or CS3) or **Same as Source** (Photoshop CS or 7) as the Print Space: Profile setting.
6. Click the **Print** or **Print One** button.
7. Click the **Properties** or **Preferences** button.
8. Click the **Advanced** button, then click **Continue**.
9. Select the media type setting for the paper you'll use for the print.



10. Select the print quality desired: **Photo** (1440 × 720 dpi), **Best Photo** (1440 × 1440 dpi), or **PhotoRPM** (5760 × 1440 dpi).
11. Turn off the High Speed and Edge Smoothing settings, if they are available.
12. Click the ICM button under Color Management and click the Off (No Color Adjustment) button.



13. Click OK.
14. Click OK or Print to print your test target.
15. Repeat these steps to print a test target for each paper type and Quality Option setting you plan to print with.

Creating a Custom Profile

If you're creating a custom profile for your printer, follow the instructions provided with your profile-building software (such as MonacoPROFILER™ by X-Rite or GretagMacbeth® ProfileMaker) to create your custom profile using the test target you printed. Once you create the profile, be sure to place it in the correct folder on your computer, as recommended by Microsoft or Apple®.

Easy Printing With Photoshop Elements 3.0

If you are using Adobe Photoshop Elements 3.0 with Windows, you can take advantage of the Epson EasyPrint interface when you're ready to print. It lets you select your basic settings directly from the Print window, so you don't need to open the Properties or Preferences window to access the printer driver.

This one-stop printing feature also prevents conflicts between software and driver settings by making them both match.

Complete instructions for using Adobe Photoshop Elements 3.0 are provided in the *Getting Started Guide* installed with Photoshop Elements.

Follow these steps to open Elements and access the EasyPrint interface:


1. To start the program, double-click the **Adobe Photoshop Elements 3.0** icon on your desktop.
2. Select **View and Organize Photos**. You see the Photo Browser workspace and **Organizer** at the top of the screen to indicate Organizer mode.
3. Select **Get Photos** from the File menu and choose an option such as **From Files and Folders**. Then select the folder containing your photo(s) and select the photo(s) you want to print.

If you need to edit a photo, go to step 4. If you are ready to print, go to step 5.

4. To edit a photo, click the **Edit** button to enter Edit mode. Choose either **Go To Quick Fix** or **Go To Standard Edit**. When you finish editing and are ready to print, click **Photo Browser** to return to Organizer mode. Do not print from Editor mode.

Note: If you print from Editor mode, you do not see the Epson EasyPrint interface. To access the printer driver settings, you must click **File > Print > Print**, select your printer name, and then click **Properties**.

5. Select **Print** from the File menu. You see the Epson EasyPrint interface:



6. Change your print settings as necessary.

7. Click **Print** to start printing.

Tip: If you're printing a borderless print and it comes out with one or more borders, select **Crop to Fit**.

Matching Black Ink to Paper Type

In order to generate the best output on a wide variety of paper types, your printer can use either the Matte Black (T059820) or Photo Black (T059120) ink cartridge. Only one can be installed in the printer at any time, but you can swap these cartridges depending on your paper type. Both are included with your printer.

Use the Matte Black ink cartridge for professional results with the following paper types:

- Presentation Paper Matte
Photo Quality Ink Jet Paper
- Ultra Premium Presentation Paper Matte
Enhanced Matte Paper
- Premium Presentation Paper Matte
Matte Paper - Heavyweight
- Premium Presentation Paper Matte Double-sided
Double-Sided Matte Paper
- Velvet Fine Art Paper
- Watercolor Paper - Radiant White
- UltraSmooth Fine Art Paper

Tip: Although these media types are available when the Photo Black cartridge is installed, printing on Matte type media with Photo Black will not yield professional or optimal results. The ability to print on matte media with Photo Black is for convenience only.

Use the Photo Black cartridge for professional results with the following paper types:

- Premium Photo Paper Glossy
Premium Glossy Photo Paper
- Ultra Premium Photo Paper Luster
Premium Luster Photo Paper
- Premium Photo Paper Semi-gloss
Premium Semigloss Photo Paper
- Proofing Paper Semimatte
- PremierArt Water Resistant Canvas

You cannot select these paper types when the Matte Black cartridge is installed.

Swapping the Black Ink Cartridges

Be sure you have the other black cartridge handy before you begin. Once you start replacing a cartridge, you must complete all the steps in one session.


You can replace a cartridge whether the red  ink light is off, flashing, or on.

1. Make sure the printer is turned on (the green  power light should be on, but not flashing). Then open the printer cover.

2. Press the  ink button.


The print head moves and the green  power light flashes.

3. Lift up the cartridge cover.
4. Press in the tab on the back of the black cartridge, and lift it out of the printer as shown below. Store this cartridge in a sealable plastic bag for later use.




5. Shake the new cartridge four or five times before opening its package. (Don't shake it after it's unwrapped.)
6. Remove the new cartridge from its package.

Caution: Don't touch the green circuit board on the front of the cartridge; you may inhibit normal operation and printing.



7. Slide the new cartridge into its slot. The side with the green circuit board goes in the front of the slot.

8. Press the cartridge down until it clicks into place.
9. Close the cartridge cover, press down on the top until it clicks, then close the printer cover.
10. Press the  ink button. The printer begins charging the new cartridge.



The green  power light and red  ink lights flash and the printer makes noise. Charging takes about 90 seconds. When it's finished, the green  power light stops flashing and stays on. The red  ink light and the light above the cartridge go out.


Caution: Never turn off the printer while the green  power light is flashing, unless the printer hasn't moved or made noise for more than 5 minutes.

Confirming the Swapped Cartridge Settings

Once you've swapped the black ink cartridges, you need to confirm that the printer driver settings are correct for the new cartridge.

Windows

1. Right-click the Status Monitor. Choose **Printer Settings** from the pop-up menu.
2. Click the **Maintenance** tab, then click **Printer and Option Information**.
3. Verify the new black ink cartridge is selected. Click **OK**.




4. Click **OK** in the Optional Ink Cartridge Notification dialog box.
5. Click **OK** in the Properties window.

Note: It may be necessary to close and re-open the application from which you're printing to update the paper Type selections.

Macintosh

1. Close any printing programs you may have open.
2. Open the Printer Setup Utility (OS X 10.3 and 10.4) or Print Center (OS X 10.2).
3. Select **Stylus Photo R2400** from the list and click the **Utility** button.
4. Click the **Epson Status Monitor** button.
5. Click the black ink cartridge and verify the new cartridge type. Then click **OK**.



6. Close the Epson Printer Utility window.

Advanced Black and White Photo Printing

The Advanced B&W Photo mode lets you easily produce neutral and toned black-and-white prints using your Epson driver and offers an alternative black-and-white workflow. Advanced B&W Photo mode also provides settings for more advanced black-and-white controls. These controls can be applied to color image files without the need to save a separate grayscale version. This mode is only available when printing at specific Quality settings on the following media types:


- Premium Photo Paper Glossy
Premium Glossy Photo Paper
- Ultra Premium Photo Paper Luster
Premium Luster Photo Paper
- Premium Semi-gloss Photo Paper
Premium Photo Paper Semigloss
- Premium Presentation Paper Matte
Matte Paper-Heavyweight
- Ultra Premium Presentation Paper Matte
Enhanced Matte Paper
- Watercolor Paper-Radiant White
- Velvet Fine Art Paper
- UltraSmooth Fine Art Paper

Follow the steps in one of these sections to use Advanced B&W Photo settings:

- “Windows” on page 74
- “Mac OS X” on page 76

Windows


1. Start your printing application and open your photo file.
2. Open the File menu and click **Print**, then click **Properties** or **Preferences**.
3. Select the appropriate **Source**, **Type**, and **Size** for your printout.
4. Click the **Advanced** button, if necessary. The Basic settings change to the Advanced Settings.
5. Click **Advanced B&W Photo** in the Color Management section.



Select Advanced B&W Photo

Then choose a preset Color Toning option, or click Settings to customize Toning options

6. Select a Color Toning option from the menu, or click **Settings** to create a customized Toning option. If you click **Settings**, the following window appears:



7. You can adjust the following settings:

- **Color Toning:** Allows you to add tone (hue) to your black and white output. The default is Neutral, which will provide you with a neutral tonal scale print. You can also choose other popular presets such as Cool, Warm, and Sepia. Note that the presets will affect the target found in the Tone Color Circle.
- **Tone:** Allows you to easily change the entire tonal scale of your black and white output.
- **Brightness:** Adjusts the overall lightness and darkness of your image.
- **Contrast:** Adjusts the difference between the light and dark areas of your image.
- **Shadow and Highlight Tonality:** Allows you to control tonality only in the shadow or highlight areas of your image.
- **Max Optical Density:** Adjusts the focus of the print. Create a soft focus print by setting the density to lower.
- **Highlight Point Shift:** If your image is prone to gloss differential, checking Highlight Point Shift will help to reduce gloss differential by adding density to the highlights of your image.


- **Tone Color Circle:** Click on any portion of this color wheel or enter corresponding values to customize the tone (hue) to add to your black and white print. The closer you select to the edge of the wheel, the more color you will add to your black and white print.
- **Preview:** Approximates the image tone based on your settings. Please note this preview will always be of the same image and is not color managed.

Mac OS X


1. Start your print application and open your photo file.
2. From the File menu, choose **Page Setup**.
3. Select the **Stylus Photo R2400** printer in the **Format For** menu, and choose the appropriate **Paper Size** and **Orientation** for your printout. Then click **OK**.
4. Select **Print** from the File menu. Then open the **Printer** menu and select **Stylus Photo R2400**.
5. Select **Print Settings** from the pop-up menu. Select the appropriate **Media Type** setting for your printout.

Note: In certain programs you may need to select **Advanced** before you can select **Print Settings**.

6. Select **Advanced B&W Photo** from the **Color** menu. Uncheck **High Speed**.



7. Select **Color Management** from the pop-up menu.



8. You can adjust the following settings:

- **Color Toning:** Allows you to add tone (hue) to your black and white output. The default is Neutral, which will provide you with a neutral tonal scale print. You can also choose other popular presets such as Cool, Warm, and Sepia. Note that the presets will affect the target found in the Tone Color Circle.
- **Tone:** Allows you to easily change the entire tonal scale of your black and white output.
- **Brightness:** Adjusts the overall lightness and darkness of your image.
- **Contrast:** Adjusts the difference between the light and dark areas of your image.
- **Shadow and Highlight Tonality:** Allows you to control tonality only in the shadow or highlight areas of your image.
- **Max Optical Density:** Adjusts the focus of the print. Create a soft focus print by setting the density to lower.
- **Highlight Point Shift:** If your image is prone to gloss differential, checking Highlight Point Shift will help to reduce gloss differential by adding density to the highlights of your image.

- **Tone Color Circle:** Click on any portion of this color wheel or enter corresponding values to customize the tone (hue) to add to your black and white print. The closer you select to the edge of the wheel, the more color you will add to your black and white print.
- **Preview:** Approximates the image tone based on your settings. Please note this preview will always be of the same image and is not color managed.

Maintaining Your Printer

Follow the instructions in this chapter to keep your printer working at its best and to prepare it for moving, if necessary:

- “Cleaning the Print Head” below
- “Replacing an Ink Cartridge” on page 82
- “Aligning the Print Head” on page 86
- “Cleaning the Printer” on page 88
- “Transporting the Printer” on page 89

Cleaning the Print Head

If your printouts are unexpectedly light, or dots or lines are missing, you may need to clean the print head. This unclogs the nozzles so they can deliver ink properly. Print head cleaning uses ink, so clean it only if quality declines.

Caution: When you don’t turn on your printer for a long time, print quality can decline, so turn it on at least once a month to maintain good print quality.

This section explains how to clean the print head using the Auto Nozzle Check and Cleaning utility and the Head Cleaning utility. Use the Auto Nozzle Check and Cleaning utility first to let the printer check and clean the nozzles. If you still notice problems with quality, you can manually clean the print head.

Note: You can also clean the print head by holding down the  ink button on the printer for three seconds (when the red  ink light is off).

Automatically Checking and Cleaning the Print Head

The Auto Nozzle Check and Cleaning utility prints a nozzle check pattern that the printer then reads to see if you have any clogged nozzles. If cleaning is needed, the printer automatically cleans the print head.


1. Make sure the printer is turned on but not printing, and the red $\triangle$ ink light is off. (If the $\triangle$ ink light is flashing or on, you need to replace a cartridge; see page 82.)
2. Load several sheets of plain, letter-size paper in the printer's sheet feeder.
3. Do one of the following:

Windows: Right-click the  icon on your taskbar (in the lower right corner of your screen). Select **Auto Head Cleaning**.

Note: If the icon does not appear, click **Start > Printer (and Faxes)**, right-click on **EPSON Stylus Photo R2400**, and select **Printing Preferences**. Select the **Maintenance** tab and click **Auto Nozzle Check and Cleaning**.

Mac OS X: Open the **Applications** folder and select **EPSON Printer Utility**. Select **SP R2400**, click **OK**, and select **Auto Nozzle Check and Cleaning**.

4. Follow the instructions on the screen. The printer prints and examines the nozzle check pattern shown below. If cleaning is necessary, it then cleans the print head and prints and checks another nozzle check pattern.



5. The utility prints and checks up to five times. If some print head nozzles are still clogged, it displays an on-screen message telling you to manually clean the print head. Follow the instructions on page 81 to clean the print head, if necessary.

If you still have print quality problems, check the solutions beginning on page 99. You can also turn the printer off and wait overnight—this allows any dried ink to soften—and then try cleaning the print head again.

Running the Head Cleaning Utility

1. Make sure the printer is turned on but not printing, and the red Δ ink light is off. (If the Δ ink light is flashing or on, you need to replace a cartridge; see page 82.)
2. Do one of the following:

Windows: Right-click the  icon on your taskbar (in the lower right corner of your screen). Select **Head Cleaning**.

Note: If the icon does not appear, click **Start > Printer (and Faxes)**, right-click on **EPSON Stylus Photo R2400**, and select **Printing Preferences**. Select the Maintenance tab and click **Head Cleaning**.

Mac OS X: Open the **Applications** folder and select **EPSON Printer Utility**. Select **SP R2400**, click **OK**, and select **Head Cleaning**.

3. Follow the instructions on the screen to clean the print head.

Cleaning takes about two minutes, during which the printer makes noise and the green Δ power light flashes.

Caution: Never turn off the printer while the green Δ power light is flashing, unless the printer hasn't moved or made noise for more than 5 minutes.



4. When the green Δ power light stops flashing, make sure paper is loaded in the printer. Click **Print nozzle check pattern**, then click **Print** (Windows) or click **Confirmation**, then click **Next** (Macintosh). The nozzle check pattern prints.
5. If the nozzle check pattern has no gaps or lines (as shown below), click **Finish**.



If the pattern has white lines or gaps (as shown below), click **Clean** to clean the print head again.



If you don't see any improvement after cleaning the print head three or four times, check the solutions beginning on page 99. You can also turn the printer off and wait overnight—this allows any dried ink to soften—and then clean the print head again.

Replacing an Ink Cartridge

When the red  ink light flashes, an ink cartridge is low on ink.

When the red  ink light stays on, you need to replace a cartridge.

You can open the printer cover to check the ink light indicating which cartridge is low on ink or needs to be replaced.

When a cartridge is more than six months old, you may need to replace it if printouts don't look their best. If the quality doesn't improve after cleaning and aligning the print head, you can replace the cartridge even if the red  ink light is off.

Caution: Don't open Epson Status Monitor, pause printing, or respond to ink messages when your printer is printing. This may cause your printer to pause and leave an uneven surface on your printout. If ink is low, wait until printing finishes before checking ink levels or replacing a cartridge. If you replace an ink cartridge in the middle of a print job, the quality of your printout may decline. For best results, check ink cartridge status and replace cartridges, if necessary, before printing large or high-resolution print jobs.

Checking the Ink Cartridge Status

To check your ink cartridge status, do one of the following:


- **Windows:** Double-click the  icon on the Windows taskbar.

You see a window like this:

- **Mac OS X:** Choose Applications > EPSON Printer Utility > SP R2400 > EPSON StatusMonitor.

You see a window like this:

Click a cartridge image to display information about the cartridge.



Purchasing Ink Cartridges

Use these Epson ink cartridges within six months of installing them and before the expiration date on the package:

Ink cartridge	Part number
Light Light Black	T059920
Light Magenta	T059620
Light Cyan	T059520
Light Black	T059720
Photo Black	T059120
Matte Black	T059820
Cyan	T059220
Magenta	T059320
Yellow	T059420

Caution: To ensure good results, use genuine Epson ink cartridges and do not refill them. Other products may cause damage to your printer not covered by Epson's warranty.

You can purchase genuine Epson ink and paper from an authorized Epson reseller. To find the nearest reseller, please call 800-GO-EPSON (800-463-7766). Or you can purchase online at www.epsonstore.com (U.S. sales) or www.epson.ca (Canadian sales).

Ink Cartridge Precautions

Warning: Keep ink cartridges out of the reach of children and don't drink the ink.

If ink gets on your hands, wash them thoroughly with soap and water. If ink gets in your eyes, flush them thoroughly with water.

Caution: To avoid damaging the printer, never move the print head by hand.

You cannot print if an ink cartridge is expended. Leave the cartridge you need to replace installed in the printer until you have obtained a replacement. Otherwise the ink remaining in the print head nozzles may dry out.

Removing and Installing Ink Cartridges

Be sure you have a new ink cartridge before you begin. Once you start replacing a cartridge, you must complete all the steps in one session.

You can replace a cartridge whether the red  ink light is off, flashing, or on.


1. Make sure the printer is turned on (the green  power light should be on, but not flashing). Then open the printer cover.
2. Press the  ink button.

The print head moves and the green  power light flashes.

If a red ink light is flashing or on (indicating a low or expended cartridge), the cartridge(s) indicated beneath the light(s) needs to be replaced.


3. Lift up the cartridge cover.

4. Press in the tab on the back of the cartridge, lift it out of the printer, and dispose of it carefully.




5. Shake the new cartridge four or five times before opening its package. (Don't shake it after it's unwrapped.)
6. Remove the new cartridge from its package.

Caution: Don't touch the green circuit board on the front of the cartridge; you may inhibit normal operation and printing.



7. Slide the new cartridge into its slot. The side with the green circuit board goes in the front of the slot.
8. Press the cartridge down until it clicks into place.



9. If you need to replace any other ink cartridges, repeat steps 4 through 8.
10. Close the cartridge cover, press down on the top until it clicks, then close the printer cover.

11. Press the  ink button. The printer begins charging the ink delivery system.

The green  power light and red  ink lights flash and the printer makes noise. Charging takes about 90 seconds. When it's finished, the green  power light stops flashing and stays on. The red  ink light and the light(s) above the cartridge(s) go out.

Caution: Never turn off the printer while the green  power light is flashing, unless the printer hasn't moved or made noise for more than 5 minutes.

Aligning the Print Head

If your printouts contain misaligned vertical lines, or you see light or dark horizontal banding, you may need to align the print head. You can have the printer automatically check and align the print head or you can check and adjust it yourself.

Automatically Aligning the Print Head

1. Make sure the printer is turned on but not printing.
2. Load at least three sheets of letter-size Epson Presentation Paper Matte (Photo Quality Ink Jet Paper).
3. Do one of the following:

Windows: Right-click the  icon on your taskbar (in the lower right corner of your screen). Select **Print Head Alignment**.

Note: If the icon does not appear, click **Start > Printer (and Faxes)**, right-click on **EPSON Stylus Photo R2400**, and select **Printing Preferences**. Select the **Maintenance** tab and click **Print Head Alignment**.

Mac OS X: Open the **Applications** folder and select **EPSON Printer Utility**. Select **SP R2400**, click **OK**, and select **Print Head Alignment**.

You see a screen like this:

4. Click the **Automatic** button, if necessary, then click **OK**.
5. On the next screen, click **Start**. The printer prints and checks an alignment pattern, and then prints and checks two more patterns.
6. When alignment is finished, click **Finish** on the last screen.



Manually Aligning the Print Head

1. Make sure the printer is turned on but not printing.
2. Load letter-size Epson Presentation Paper Matte (Photo Quality Ink Jet Paper).
3. Do one of the following:

Windows: Right-click the  icon on your taskbar (in the lower right corner of your screen). Select **Print Head Alignment**.

Note: If the icon does not appear, click **Start > Printer (and Faxes)**, right-click on **EPSON Stylus Photo R2400**, and select **Printing Preferences**. Select the **Maintenance** tab and click **Print Head Alignment**.


Mac OS X: Open the **Applications** folder and select **EPSON Printer Utility**. Select **SP R2400**, click **OK**, and select **Print Head Alignment**.

4. Click the **Manual** button, then click **OK**. You see a screen like this as the printer prints an alignment check pattern:

5. On the check page, select the box in each pattern with the least noticeable lines. You may need to use a magnifying glass. Select one box for each pattern numbered 1 through 3. Then enter the box number for each pattern in the boxes on the screen.

If box #5 is *not* the best-aligned box in each pattern, click **Realignment** to print another test page and repeat this step.


6. When box #5 is the best-aligned in all the patterns, click **Finish**.



Cleaning the Printer

To keep your printer working at its best, you should clean it several times a year.

1. Turn off the printer, unplug the power cord, and disconnect the interface cable.
2. Remove all the paper, then use a soft brush to clean the paper feeders.
3. Clean the exterior of the printer with a soft, damp cloth. Keep the paper support and printer cover closed as you clean the printer.
4. If you need to clean ink out of the inside of the printer, use a soft cloth to clean only the black plastic area shown below:



Warning: Don't touch the gears or rollers inside the printer.

Caution: Never use a hard or abrasive brush, or benzine, alcohol, or thinner for cleaning; they can damage the printer components and case.


Don't get water on the printer components and don't spray or apply lubricants or oils inside the printer.

Don't use any cleaning sheets included with special paper; they may jam inside the printer.

Transporting the Printer

If you move your printer some distance, you need to prepare it for transportation in its original box or a similar one. Follow these steps:

1. Turn on the printer, and wait for the ink cartridge holder to move right to the home position.
2. Turn off the printer, unplug the power cord, and disconnect the interface cable.
3. Open the printer cover and tape the ink cartridge holder to the printer case using packing tape. Then close the printer cover.



Caution: Be sure to remove the tape after installing the printer in its new location.

4. Remove any paper from the printer, then remove the roll paper holder or single sheet guide, if it is installed.
5. Close the output tray and the paper support.
6. Repack the printer and its attachments in the original box using the protective materials that came with them.

Keep the printer level as you transport it.

After transporting the printer, remove the tape you used in step 3. Then test your printer. If you notice a decline in print quality, clean the print head (see page 79); if output is misaligned, align the print head (see page 86).


Solving Problems

See “Diagnosing Printer Problems” on page 94 to help determine what the cause of your printer problem may be. Then see these sections for solutions:

- “Setup and Software Installation Problems” on page 97
- “Printer Problems” on page 98
- “Quality Problems” on page 99
- “Paper Problems” on page 101
- “Miscellaneous Problems” on page 104
- “Uninstalling and Reinstalling Printer Software” on page 105
- “Where To Get Help” on page 106

Tip: It’s a good idea to check Epson’s support website periodically for free updates to your printer driver. Visit <http://support.epson.com>. Download instructions are posted for your convenience.

Printer Parts



Printer Buttons

The table below summarizes the functions of the printer buttons.

Button	Uses
 power	Turns the printer on and off. Hold down the button until the  power light comes on or goes off.
 paper	Loads or ejects paper. Resumes printing after a paper-out or multiple-sheet-feed error. Clears paper error after unloading roll paper. Cancels a print job while printing.
 ink	Moves the print head to the ink cartridge replacement position and returns it to its home position. Cleans the print head. Hold down the button for 3 seconds when the red  ink light is off.
 roll paper	Prints a cutting guideline and feeds roll paper to the removal position after roll paper printing. Returns roll paper to the printing position after cutting. Reverses roll paper or paper in the single sheet guide out of the printer when held down for 3 seconds.

Printer Lights

The table below summarizes the functions of the printer lights.

Light	Meaning
Red 𐀀 paper out	On: printer is out of paper, multiple sheets have fed, or the wrong size sheet has fed. Flashing: paper isn't loaded for the currently selected paper path, or paper is jammed.
Red 𐀁 ink (eight)	On: an ink cartridge is expended, or the Photo Black or Matte Black cartridges were swapped during printing. Flashing: an ink cartridge is low on ink.
Green 𐀂 power	On: printer is turned on. Flashing: printer is receiving a print job, printing, replacing or charging ink, or cleaning the print head.

Diagnosing Printer Problems

First, check the printer's lights (see below) or run a printer check (see page 96).

Lights	Explanation
Green 𐀂 power light flashes	The printer is receiving a print job, printing, replacing or changing ink, or cleaning the print head.
Red 𐀁 ink light flashes	An ink cartridge is low on ink. Make sure you have a replacement cartridge, then follow the steps on page 84 to install it.
Red 𐀁 ink light on	An ink cartridge is expended, not installed, not installed correctly, or is not compatible with the printer. Follow the steps on page 84 to install or reinstall the cartridge correctly. The Photo Black or Matte Black cartridges were swapped during printing. Replace the original cartridge type in use before the error occurred.

Lights	Explanation
Red  paper light on	Your paper ran out, or multiple sheets fed. Sheet Feeder: If paper is out, load more paper and press the  paper button. If multiple sheets fed, press the  paper button to eject the paper, then turn your printer off and then on. For loading instructions, see page 12. Single Sheet Guide: See page 17 for instructions on loading single sheets of special papers. Roll Paper: See page 21 for instructions on loading or reloading roll paper. Front Path: See page 25 for instructions on loading or reloading thick media.
Red  paper light flashes	Jammed paper is blocking print head movement, or you're trying to print on paper loaded into a path different than the path specified in the printer driver. If you suspect a paper jam, turn off the printer and pull out the jammed paper. Open the cover and remove any jammed or torn paper. Then do one of the following: Sheet Feeder or Single Sheet Guide: Turn on the printer, reload paper, and press the  paper button. Roll Paper: Cut off the printed portion, then remove the paper (see page 43) and reload it (see page 21). Front Path: See page 25 for instructions on loading or reloading thick media. If a print job was sent to one paper path, but media is loaded only for another paper path, load the paper in the correct path.
Red  paper light flashes quickly Red  ink light flashes quickly	Jammed paper or a foreign object is preventing the print head from returning to the home position, or paper is loaded in the sheet feeder and the front path door is open. Turn off the printer, open the printer cover, and remove any jammed or torn paper, or foreign object. Close the front path door if it is open. Then turn the printer back on. If the error persists, contact your dealer or Epson; see page 106.

Lights	Explanation
Green  power light flashes	An unknown printer error has occurred. Turn off the printer, wait a few seconds, and turn it on again. If the lights are still flashing, contact your dealer or Epson; see page 106.
Red  paper light flashes slowly	
Red  ink light flashes slowly	

Running a Printer Check

You can run a printer check to determine whether a problem comes from the printer or some other source.

1. Turn off your printer and computer, then disconnect the printer's interface cable.
2. Load letter-size paper in the sheet feeder.
3. Hold down the  paper button, then press and release the  power button.
Continue to hold down the  paper button until the  power light flashes.
4. A test page prints the printer's ROM version number and a nozzle check pattern.
 - If the check page prints, the problem probably lies in your software settings, interface cable, or computer, or your software may not be installed correctly.
 - If the check page doesn't print, the printer may have a problem.

Try the suggestions in "Problems and Solutions" beginning on page 97.
5. Turn off the printer, connect the interface cable, and turn on your printer and computer.

Problems and Solutions

Setup and Software Installation Problems

The printer makes noise after ink cartridge installation.

- When you install ink cartridges, the printer must charge its print head for about two and a half minutes. Wait until it's finished (the green  power light stops flashing) before you turn off the printer, or it may use excess ink the next time you turn it on.
- Make sure the ink cartridges are inserted completely, the ink cover is closed, and no packing material remains in the printer. Turn off the printer, wait a moment, then turn it back on to clear the error.

You're having problems installing or using the printer software.

- Make sure your printer is turned on and its cable is securely connected at both ends. Follow the installation steps on the *Start Here* sheet, and make sure your system meets the requirements on page 109.
- Close other programs, including screen savers and virus protectors, and install again.
- If you see an error message with Windows 2000, you may not have software installation privileges. Contact your System Administrator.
- If you're using Windows and the USB port, make sure your system was not upgraded from Windows 95; the USB driver may not install correctly.
- If you're using Windows Vista, you cannot connect the printer using a FireWire cable; you must use a USB cable.
- If you're printing over a network, see your on-screen *Reference Guide* for instructions on configuring your printer for use on a network.
- In Windows, make sure your printer is selected as the default printer in the Printers utility.

Printer Problems

Only the green  power light is on, but nothing prints.

- Make sure the interface cable is securely connected at both ends and meets the system requirements on page 109.
- Run a printer check as described on page 96. If the test page prints, make sure your software is installed correctly.
- If you're printing on a network, make sure you set up your printer for network printing, as described in your on-screen *Reference Guide*.

The printer sounds as though it is printing, but nothing prints.

- The print head may need cleaning; see page 79 for instructions.
- The printer won't operate properly if it's tilted or at an angle. Place it on a flat, stable surface.

Your printer makes noise when you turn it on or after it has been sitting for awhile.

Your printer is performing routine maintenance.

Printing is too slow.

Make sure your system meets the recommended requirements listed on page 109. You may also need to:

- Clear space on your hard drive or run a defragmentation utility.
- Close open programs that you're not using.
- Increase your system's memory (RAM).

For the fastest printing:

- Select **Draft** (Windows) or set the Quality/Speed slider to **Speed** (Macintosh).
- Turn **High Speed** on and turn **Finest Detail** off, if available.
- If your printer is connected to a USB hub, disconnect any unused USB devices. Use a Hi-Speed USB 2.0 cable connected to a Hi-Speed USB 2.0 port.

Quality Problems

You see banding (light lines).

- Clean the print head; see page 79 for instructions.
- Select a higher print quality and turn off **High Speed** mode; see page 31 (Windows) or page 39 (Macintosh).
- Select the correct **Type** or **Media Type** setting for your paper; see page 41.
- Make sure the printable side of the paper is face-up; it's usually whiter or shinier.
- The ink cartridges may need replacing; see page 82.
- Align the print head as described on page 86.



Your print is blurry or smeared.

- Make sure your paper isn't damp, curled, or loaded face down (load new paper face-up).
- Use a support sheet with special paper, or try loading your paper one sheet at a time.
- Make sure your paper meets the specifications listed in the on-screen *Reference Guide*.
- Use Epson papers for proper saturation and absorption of Epson inks. If you use a paper not listed under the supported paper types, you may see smears, roller marks, misting, or other problems in your printouts; see page 11.
- Align the print head as described on page 86.
- Select the **Thick paper** checkbox in your printer software. Access the setting from the printer settings window as follows:



Windows: Click **Maintenance** and select **Printer and Option Information**.

Mac OS X: Select **Extension Setting** from the pop-up menu.

Your printout is faint or has gaps.

- Clean the print head; see page 79 for instructions.
- The ink cartridges may be old or low on ink; see page 82.
- Select the correct Type or Media Type setting for your paper in the printer driver; see page 41.
- Make sure your paper isn't damaged, old, dirty, or loaded face-down. For best results, use genuine Epson paper.



Caution: Don't open Epson Status Monitor, pause printing, or respond to ink messages when your printer is printing. This may cause your printer to pause and leave an uneven surface on your printout. If ink is low, wait until printing finishes before checking ink levels or replacing a cartridge. If you replace an ink cartridge in the middle of a print job, the quality of your printout may decline. For best results, check ink levels and replace cartridges, if necessary, before printing large or high-resolution print jobs.

Your printout is grainy.

- Use a higher quality paper or select a higher print quality (for Windows, see page 31; for Macintosh, see page 39).
- Align the print head as described on page 86.
- Increase the image resolution or print it in a smaller size; see your software documentation.
- Make sure you're not printing a PostScript® file.

You see wrong or missing colors.

- Make sure **Color** ink is selected (Macintosh), even when printing black and white photographs, unless you are using Advanced B&W Print settings.
- Clean the print head; see page 79 for instructions.
- The ink cartridges may be old or low on ink; see page 82.

- Try turning off PhotoEnhance (Windows). Also check if you're using a special effect that alters image colors, like Sepia.
- Change the **Gamma** setting (Macintosh); see page 39.
- Your printed colors can never exactly match your on-screen colors. However, you can use a color management system to get as close as possible. See the Photoshop color management instructions on page 53. If your photos have a dark, underexposed and/or yellow-brown cast or a light, overexposed and or light-blue cast after using color management, see the solutions on page 62.

Paper Problems

Paper doesn't eject fully or is wrinkled.

- If the paper doesn't eject fully, you may have set the wrong paper size. Press the  paper button to eject the paper, then select the correct paper size.
- If it's wrinkled when it ejects, the paper may be damp or too thin. Load new paper.

Paper sheets don't feed correctly.


- If paper doesn't feed or multiple pages feed, remove it from the sheet feeder. Fan the edges of the sheets, reload them against the right side of the feeder, and slide the left edge guide against the paper, but not too tightly. Don't load paper above the arrow on the left edge guide.
- If you are loading multiple sheets of matte paper that are larger than letter-size, use the matte paper support. See page 15.

Paper sheets jam in the printer.

Press the  paper button to eject the jammed paper. If that doesn't work, try the following:

1. Turn off the printer.
2. Remove any jammed paper from the printer's output tray.

3. Remove any jammed paper from the sheet feeder or open the printer cover and remove any paper jammed inside. Press the  paper button to clear the error.



Roll paper or canvas doesn't feed correctly or jams in the printer.

- Cut the end of the paper straight across. If the edge is uneven or frayed, the paper won't feed smoothly.
- If the roll paper end is curled, place the end inside a folded sheet of paper and roll it backwards against the curl.
- Make sure the paper is loaded in the roll paper feeder, not the sheet feeder; see page 21.
- As you load the paper, gently hold it in the roll paper feeder and wait for it to load; don't force the paper in.
- Select **Roll** as the Source (Windows) or the correct size and source of **Roll Paper** for the Paper Size (Macintosh). Other settings will feed too much paper. See page 43 for instructions.
- If extra paper feeds, press the  roll paper button for three seconds to rewind the paper all the way (repeat if necessary). If the  paper light is on, press the  paper button. Reload the paper as described on page 21.

Note: For certain paper types, clearing a paper jam may leave behind a fine layer of paper dust, which may then appear on your next printout. To prevent this, use a can of compressed air to blow paper dust out of the printer after clearing a paper jam. Open the front path door and direct the airflow through the roll paper feeder (under the white rollers) at the back of the printer. Start on the home position side and move across. Do not blow paper dust into the home position area.

There is fiber or dust on the paper rollers, preventing paper from feeding properly.

Paper dust may have built up on the paper rollers, preventing paper from feeding properly. Use Epson Ink Jet Printer Cleaning Sheets (part number S041150) to clean the rollers.


Caution: Do not use the cleaning sheets that come with Epson special papers; they may jam inside your printer.

Follow these steps to clean the paper rollers:

1. Remove any paper loaded in the printer's sheet feeder.
2. Remove the instruction sheet from the sticky side of the cleaning sheet.

Caution: Do not follow the loading instructions on the sheet; they are not correct for your printer. Follow the steps here instead.

3. Position the cleaning sheet in the printer's sheet feeder as shown below. Make sure the sticky side of the cleaning sheet is face-up.



4. Press the  paper button to feed the sheet through the printer.
5. When the sheet ejects, repeat steps 3 and 4 to feed the sheet through two more times. Then discard the cleaning sheet.

Miscellaneous Problems

The image is inverted, as if viewed in a mirror.

Turn off **Mirror Image** in the printer software or the mirror setting in your program. See page 31 (Windows) or page 39 (Macintosh) for instructions.

The printer prints blank pages.

- Make sure your printer is selected in the Print window, or in the Macintosh Printer Setup Utility or Print Center.
- Clean the print head; see page 79 for instructions.

You see incorrect characters.

- Make sure the interface cable is securely connected at both ends and meets the system requirements on page 109.
- Make sure your printer is selected in the Print window, or in the Macintosh Printer Setup Utility or Print Center.
- If you're using a switch box or USB hub with your printer, connect the printer directly to your computer instead.

The margins are incorrect.

- Make sure the paper settings are correct for your paper size. See page 28 (Windows) or page 33 (Macintosh).
- Choose the correct margins for your paper size. The margins must be within the printable area of the page; see "Printer Specifications" in your on-screen *Reference Guide*.
- Place your paper against the right side of the feeder with the left edge guide snug against it.
- Make sure the **Borderless** setting is set correctly for your margins; see page 43 for roll paper or page 49 for cut sheets.

Too many copies printed.

Make sure that the Copies option in your printer software or program is not set for multiple copies.

Image size/position is incorrect.

Make sure the paper and layout options are set correctly.

Uninstalling and Reinstalling Printer Software

You may need to uninstall and then reinstall your printer driver and utilities if, for example, you upgrade your Windows operating system. You don't need to uninstall your other photo software or the Epson *Reference Guide*.

Windows

1. Click **Start**, and select **Programs** or **All Programs**.
2. Point to **EPSON** or **EPSON Printers**, then select **EPSON Printer Software Uninstall**.
3. In the next window, select **EPSON Stylus Photo R2400** and click **OK**. Then follow the on-screen instructions.

In Windows Vista, when you see the User Account Control screen, click **Continue**, then go to step 4.

4. Restart your computer, then see the *Start Here* sheet to reinstall your software.

Mac OS X

1. Open the **Applications** folder, then the **Utilities** folder.
2. Select **Printer Setup Utility** or **Print Center**, select **Stylus Photo R2400**, and click the **Delete** button.
3. Insert your Epson Printer Software CD-ROM into your drive.

4. Double-click the **SPR2400** icon, then double-click the **Vise** icon. Click **Continue**.
5. Select **Uninstall** from the drop-down menu, then follow the on-screen instructions to remove the printer software.
6. Restart your Macintosh, then see the *Start Here* sheet to reinstall your software.

Where To Get Help

If you need help with your printer, see the information below.

For help with other software that came with your printer, see page 107.

Epson Technical Support

Epson provides these technical support services:

Internet Support

Visit Epson's support website at epson.com/support and select your product for solutions to common problems. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative

Before you call for support, please have the following information ready:

- Product name (Epson Stylus Photo R2400)
- Product serial number (located on the back of the printer and on its box)
- Proof of purchase (such as a store receipt) and date of purchase
- Computer configuration and operating system version
- Description of the problem

Then call:

■ U.S.: (562) 276-7296, 6 AM to 8 PM, Pacific Time, Monday through Friday and 7 AM to 4 PM, Saturday.

■ Canada: (905) 709-2567, 6 AM to 6 PM, Pacific Time, Monday through Friday.

Toll or long distance charges may apply.

Purchase Supplies and Accessories

You can purchase genuine Epson ink and paper from an authorized Epson reseller. To find the nearest reseller, please call 800-GO-EPSON (800-463-7766). Or you can purchase online at www.epsonstore.com (U.S. sales) or www.epson.ca (Canadian sales).

Technical Support for Other Photo Software

Software	Web site or e-mail	Telephone
nik Multimedia	supportus@nikmultimedia.com	(619) 725-3150, 8:30 AM to 5 PM, Monday to Friday, Pacific Time

Requirements and Notices

Windows System Requirements

To use your printer and its software, we recommend that your system has:

- Microsoft Windows compatible PC with a Pentium® III-class 800 MHz or higher processor (Pentium 4-class, 2 GHz or higher recommended)
- Windows 2000, XP, XP Professional x64 Edition, or Windows Vista
- 512MB RAM (2GB recommended)
- 300MB hard disk space (1GB recommended)
- 4x or faster CD-ROM or DVD-ROM drive for installing the printer software
- USB connection: a Windows-compliant USB 1.1 port or Hi-Speed USB 2.0 port (recommended) and a shielded USB “AB” cable (Hi-Speed USB 2.0 recommended), 2 meter (6.5 ft) max. length
IEEE-1394 (FireWire) connection: an OHCI-compliant IEEE-1394 port and an IEEE-1394 cable; FireWire connection not supported in Windows Vista

Macintosh System Requirements

To use your printer and its software, we recommend that your system has:

- An Apple® Mac-class computer with one or more: PowerPC® G4 733 MHz (1 GHZ recommended), PowerPC G5, or Intel® Core™ processor
- Mac OS X 10.2.8, 10.3.9 through 10.4.x
- 512MB RAM (2GB recommended)
- 300MB hard disk space (1GB recommended)
- 4x or faster CD-ROM or DVD-ROM drive for installing the printer software
- USB connection: a shielded USB “AB” cable (Hi-Speed USB 2.0 recommended), 2 meter (6.5 ft) max. length
FireWire connection: an OHCI-compliant FireWire port and a FireWire cable

Important Safety Instructions

Before using your printer, read these safety instructions to make sure you use it safely and effectively:

- Be sure to follow all warnings and instructions marked on the printer.
- Use only the type of power source indicated on the printer's label.
- Connect all equipment to properly grounded power outlets. Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off.
- Place the printer near a wall outlet where the plug can be easily unplugged.
- Do not let the power cord become damaged or frayed.
- If you use an extension cord with the printer, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the outlet's ampere rating.
- Keep your printer and computer system away from potential sources of electromagnetic interference, such as loudspeakers or cordless telephone base units.
- Avoid locations that are subject to rapid changes in heat or humidity, shocks or vibrations, or dust.
- Leave enough room around the printer for sufficient ventilation, leaving at least 3.9 inches between the back of the printer and the wall.
- Do not place the printer near a radiator or heating vent or in direct sunlight.
- Place the printer on a flat, stable surface that extends beyond the printer base in all directions. The printer will not operate properly if it is tilted or at an angle.
- When transporting or storing the printer, don't tilt it, stand it on its side, or turn it upside-down. This may allow ink to leak from the ink cartridges.
- Turn off and unplug the printer before cleaning. Clean with a damp cloth only. Do not spill liquid on the printer.

Caution: Always turn the printer off using the  power button. Don't switch off the power strip or unplug the printer until the green  power light is off.

- Do not block or cover the openings in the printer's case or insert objects through the slots.
- Except as specifically explained in this manual, do not attempt to service the printer yourself.
- Unplug the printer and refer servicing to qualified service personnel under the following conditions:

If the power cord or plug is damaged; if liquid has entered the printer; if the printer has been dropped or the case damaged; if the printer does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.

Ink Cartridge Safety Instructions

- Keep ink cartridges out of the reach of children.
- Be careful when you handle used ink cartridges; there may be ink remaining around the ink supply port. If ink gets on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water.
- Do not put your hand inside the printer or touch a cartridge during printing.
- Do not move the print head by hand. You may damage the printer.
- Install the ink cartridge immediately after you remove it from its package. Leaving the cartridge unpacked for a long time before use can result in reduced print quality.
- Do not use an ink cartridge beyond the date printed on the cartridge carton. For best results, use up the ink cartridges within six months of first installing them.
- Store ink cartridges in a cool, dark place.
- Store ink cartridges with the bottom of the packaging facing down.
- After bringing an ink cartridge inside from a cold storage site, allow it to warm up at room temperature for at least three hours before using it.
- Shake an ink cartridge 4 or 5 times before removing it from its package.
- Do not shake an ink cartridge after removing it from its package; this can cause leakage.
- Do not remove or tear the label on an ink cartridge; this can cause leakage.
- Do not dismantle the ink cartridges or try to refill them. This could damage the print head.
- Do not touch the green IC chip on the front of the cartridge. This may affect normal operation and printing.
- If you remove an ink cartridge for later use, protect the ink supply area from dirt and dust and store it in the same environment as the printer. Note that there is a valve in the ink supply port, making covers or plugs unnecessary, but care is needed to prevent the ink from staining items that the cartridge touches. Do not touch the ink cartridge ink supply port or surrounding area.

FCC Compliance Statement

For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

For Canadian Users

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity

According to 47CFR, Part 2 and 15 for Class B Personal Computers and Peripherals; and/or CPU Boards and Power Supplies used with Class B Personal Computers:

We: Epson America, Inc.
Located at: MS: 3-13
3840 Kilroy Airport Way
Long Beach, CA 90806
Telephone: (562) 290-5254

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR §2.909. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Trade Name: Epson
Type of Product: Ink Jet Printer
Model: B321A

Epson America, Inc. Limited Warranty

What Is Covered: Epson America, Inc. (“Epson”) warrants to the original retail purchaser that the Epson printer covered by this limited warranty statement, if purchased and operated only in the United States or Canada, conforms to the manufacturer’s specifications and will be free from defects in workmanship and materials for a period of one (1) year from the date of original purchase. Epson also warrants that the consumable ink cartridges enclosed with the printer will perform to the manufacturer’s specified usage, which usage may expire before the expiration of the limited warranty for the Epson printer. For warranty service, you must provide proof of the date of original purchase.

What Epson Will Do To Correct Problems: Should your Epson printer prove defective during the warranty period, please call the Epson ConnectionSM at (562) 276-7296 (U.S.) or (905) 709-2567 (Canada) for warranty repair instructions and return authorization. An Epson service technician will provide telephone diagnostic service to determine whether the printer requires service. If service is needed, Epson will, at its option, exchange or repair the printer without charge for parts or labor. If Epson authorizes an exchange for the defective unit, Epson will ship a replacement printer to you, freight prepaid, so long as you use an address in Canada or the U.S. (excluding Puerto Rico and U.S. Possessions). Shipments to other locations will be made freight collect. You are responsible for securely packaging the defective unit and returning it to Epson within five (5) working days of receipt of the replacement. Epson requires a debit or a credit card number to secure the cost of the replacement

printer in the event that you fail to return the defective one. If your printer is being repaired, Epson will direct you to send your printer to Epson or its authorized service center, where the printer will be fixed and sent back to you. You are responsible for packing the printer and for all costs to and from the Epson authorized service center. When warranty service involves the exchange of the printer or a part, the item replaced becomes Epson property. The replacement printer or part may be new or refurbished to the Epson standard of quality, and, at Epson's option, may be another model of like kind and quality. Epson's liability for replacement of the covered printer will not exceed the original retail selling price of the covered printer. Exchange products and parts assume the remaining warranty period of your original product covered by this limited warranty.

What This Warranty Does Not Cover: This warranty does not apply to refurbished or reconditioned products. This warranty covers only normal use in the United States and Canada. Using this product for continuous production or similar high duty purposes is not considered normal use; damage, maintenance or service from such use will not be covered under this warranty. This warranty is not transferable. This warranty does not cover any color change or fading of prints or reimbursement of materials or services required for reprinting. This warranty does not cover damage to the Epson product caused by parts or supplies not manufactured, distributed or certified by Epson. This warranty does not cover ribbons, ink cartridges or third party parts, components, or peripheral devices added to the Epson product after its shipment from Epson, e.g., dealer or user-added boards or components. Epson is not responsible for warranty service should the Epson label or logo or the rating label or serial number be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, improper installation, neglect, improper shipping, damage caused by disasters such as fire, flood, and lightning, improper electrical current, software problems, interaction with non-Epson products, or service other than by an Epson Authorized Servicer. If a claimed defect cannot be identified or reproduced, you will be held responsible for the costs incurred.

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSON OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, NEITHER EPSON AMERICA, INC. NOR ITS AFFILIATES SHALL BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE EPSON PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

In Canada, warranties include both warranties and conditions.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Epson America, Inc. ■ P. O. Box 93012 ■ Long Beach, CA 90809-3012

Index

A

- Adobe Photoshop, managing color with, 53 to 66
- Advanced B&W Photo mode, 73 to 78
- Advanced settings
 - Macintosh, 39 to 40
 - Windows, 31 to 33
- Aligning print head, 86 to 87
- Automatic
 - print head aligning, 86 to 87
 - print head cleaning, 80
- Automatic mode, Macintosh, 36

B

- Background printing, 38
- Banding, 99
- Basic printing
 - Macintosh, 33 to 38
 - Windows, 28 to 30
- Best Photo setting, 29, 50
- Blank pages, 104
- Blurry images, 99
- Borderless setting, 29, 49 to 52
- Bright White Paper, 14, 41
- Browser, 10
- Buttons, 93, 95 to 96

C

- Cable, printer, 109
- Cancelling printing
 - Macintosh, 38
 - Windows, 30
- Canvas, *see* Roll paper
- Characters, incorrect, 104
- Checking printer, 96

- Cleaning
 - print head, 79 to 82
 - printer, 88
- Color management
 - menu, Macintosh, 37
 - problems, 62
 - settings, 31 to 32, 37, 40, 53 to 66
 - with color profiles, 53 to 66
- Color problems, 62, 100
- ColorSync, 40
- Control panel, 92 to 93, 96
- Controlling printing
 - Macintosh, 38
 - Windows, 30
- Custom profiles, 62 to 66
- Custom settings
 - Macintosh, 39 to 40
 - Windows, 31 to 33

D

- Declaration of Conformity, 113
- Default settings, Windows, 30
- Documentation, 9 to 10
- Draft setting, 29, 98
- Dust, paper, 102

E

- Edge Smoothing setting
 - color management, 56, 61, 64, 66
 - Windows, 32
- Electronic manual, 9 to 10
- Enhanced Matte Paper, 14, 41
- Epson
 - help, 106 to 107
 - papers, 14, 41, 49
 - PhotoCenter, 8
 - warranty, 113 to 114

Exif Print, description, 8
Expansion setting, 50, 52
Extension setting, 37, 99

F

Faint images, 100
FCC Compliance Statement, 112
Features, 7

G

Gamma setting, Macintosh, 101
Glossy photo paper, 14, 41, 44, 47, 49
Grainy prints, 100

H

Head Cleaning utility, 81 to 82
Help
 Epson, 106 to 107
 other software, 107
 see also Troubleshooting
High Speed setting, 98 to 99

I

ICM (Image Color Matching) setting, 32, 57, 66
Incorrect
 characters, 104
 colors, 62, 100
 margins, 104
Ink cartridge
 level of ink in, 83
 ordering, 83 to 84
 problems, solving, 94, 97
 replacing, 82 to 86
 safety instructions, 84, 111

Ink level, checking
 Macintosh, 83
 Windows, 83
Installation problems, 97
Inverted image, 104

J

Jams, paper, 95, 101 to 102

L

Layout problems, 105
Layout settings
 Macintosh, 37
 Windows, 33
Letterhead, 13
Light Black ink cartridge, 7, 83
Light Light Black ink cartridge, 7, 83
Lights, 94 to 96
Luster photo paper, 14, 41, 44, 47

M

Macintosh
 basic printing, 33 to 38
 custom printing, 39 to 40
 system requirements, 109
 uninstalling software, 105 to 106
Maintaining printer, 79 to 88
Margins, incorrect, 104
Matte Black ink cartridge, 7, 68, 83
Matte paper, 14, 15, 41, 49
Matte sheet support, 15 to 16
Media Type setting, Macintosh, 36, 41, 47
Mirror images, 104
Monitoring ink level
 Macintosh, 83
 Windows, 83
Moving printer, 89

N

Network printing, 97
Noise, printer, 98
Nozzle Check, 80 to 82

O

Orientation setting, 29, 35

P

Page Setup, Macintosh, 35
Paper
 Epson, 14, 41, 49
 feeding problems, 101 to 102
 jams, 95, 101 to 102
 loading in sheet feeder, 12 to 13
 loading in single sheet guide, 17 to 20
 loading multiple matte sheets, 15 to 16
 loading special, 14
 roll, *see* Roll paper
Paper dust, 102
Paper Size setting, 34 to 35
Paper Source setting, 20, 26, 35
Paper Type setting, Windows, 29, 41, 44
Photo Black ink cartridge, 7, 68, 83
Photo RPM setting, 31, 39
Photo setting, 29, 50
Photo software, 8
PhotoCenter, Epson, 8
PhotoEnhance, 29, 101
PremierArt Paper, 17, 49
Premium Bright White Paper, 14, 41
Premium Glossy Photo Paper, 14, 41, 44, 47, 49
Premium Luster Photo Paper, 14, 41, 44, 47, 49
Premium Semigloss Photo Paper, 14, 41, 44, 47, 49
Preprinted paper, 13

Print Center, Macintosh, 38
Print dialog box, Windows, 28, 30
Print head
 aligning, 86 to 87
 cleaning, 79 to 82
Print Head Alignment utility, 86 to 87
Print Quality
 problems, 99 to 100
 setting, 39, 64
Print Settings menu, Macintosh, 36
Printer
 cable, 109
 check, 96
 cleaning, 88
 control panel, 92 to 93, 96
 maintaining, 79 to 88
 noise, 98
 parts, 92
 problems, 94 to 96, 98
 transporting, 89
Printing
 Macintosh, advanced, 39 to 40
 Macintosh, basic, 33 to 38
 Windows, advanced, 31 to 33
 Windows, basic, 28 to 30
Problems
 diagnosing, 94 to 96
 installing software, 97
 miscellaneous, 104 to 105
 paper feeding, 101 to 102
 print quality, 99 to 100
 printer, 98
 solving, 91 to 107
 uninstalling software, 105 to 106

Q

Quality Option setting, 29, 50, 56, 66
Quality/Speed setting, 36, 47, 52, 98

R

- Reference Guide, 9 to 10
- Reinstalling software, 106
- Roll paper
 - button, 48
 - controlling printing, 48
 - holder, 22 to 24, 48
 - loading, 21 to 24, 43
 - options, 45, 47
 - printing on, 43 to 47
 - problems, solving, 95, 102
 - removing, 48
 - storing, 48

S

- Safety instructions, 110 to 111
- Semigloss photo paper, 14, 41, 44, 47
- Service, 106 to 107
- Sheet feeder
 - loading paper in, 12 to 13
 - problems, solving, 95, 101 to 102
- Single sheet guide, 17 to 20
- Size setting, 29, 44
- Slow printing, 98
- Smear printout, 37, 99
- Software
 - installation problems, solving, 97
 - photo, 8
 - reinstalling, 106
 - summary, 8
 - uninstalling, 105 to 106
- Source setting, 20, 26, 29, 45, 50
- Support, 106 to 107
- System requirements, 109

T

- Technical support, 106 to 107
- Testing printer, 96
- Text & Image setting, 29
- Text setting, 29
- Thick paper setting, 37, 99
- Transporting printer, 89
- Troubleshooting, 91 to 107
- Type setting, Windows, 29, 41, 44

U

- Uninstalling software, 105 to 106
- USB, 97, 104, 109
- Utilities
 - Auto Nozzle Check and Cleaning, 80
 - Head Cleaning, 81 to 82
 - Nozzle Check, 80 to 82
 - Print Head Alignment, 86 to 87

V

- Velvet Fine Art Paper, 17, 49

W

- Warranty, 113 to 114
- Watermark, 33
- Windows
 - advanced printing, 31 to 33
 - basic printing, 28 to 30
 - default settings, 30
 - system requirements, 109
 - uninstalling software, 105 to 106

