

# C series

# User Manual

Version: 1.0


# Content

- Chapter 1 LCD Screen Introduction: .....2
- Chapter 2 Operating Detailed .....3
  - Section 1 Pressure and Speed .....4
  - Section 2 Language and Optimization .....4
  - Section 3 Copy and Mode .....6
  - Section 4 Distance between light dot and pen.....7
  - Section 5 Cutting Proportion .....8
  - Section 6 X, Y axis scale .....9
  - Section 7 Cutting from FLASH.....10
  - Section 8 U disk Working.....10
  - Section 9 Pressure test .....11
  - Section 10 Pause and Cancel during operating .....12

## Chapter 1 LCD Screen Introduction:




Machine control method:




1. Power-on, the screen show as X and Y axis


## 2. Key operation

Panel description:








## Chapter 2 Operating Detailed





When the machine power on, it will show like  , the information display area will show the number of X and Y axis, the X axis will returns to the origin position when the machine power-on again. Y axis will move forward a short distance. In the process of returning the X axis to the origin position, pressing any button on the keyboard , the X axis will be cancel returning to origin.

## Section 1 Pressure and Speed (primary menu)



## Section 2 Language and Optimization (secondary menu)





Then , press origin button into

(The factory setting of language is English, customer don't need to adjust it)



The optimized value is adjusted by direction buttons. Press for increase,





press for decrease.



The optimization values are described in the following table, the default value is zero.


| Value | meaning   | Usage condition  |
|-------|---|--|
| 0     | Air speed, cutting long line speed is fastest, not limited by speed regulation                            | When it is not necessary to drag the whole roll of material and the material that is not very thick and hard |
| 1     | When the value less than 1, the air speed and long line speed is not limited by speed regulation          | When it need to drag the small roll material   |
| 2     | When the value less than 2, the air speed and cutting long line speed is not limited by speed regulation. | When its need to drag heavy materials  |
| 3     | When the value more than 2, the air speed and cutting long line speed are set by speed regulation         | When cutting thick and hard materials  |


### Section 3 Copy: Times of repeat cutting| and Mode: Go Home after working finished (third level menu)



Press menu button  into  , then press origin

button  into  .



 it represents the number of repeated cuts, press  button for

increasing the number of repeated cuts, press  button for decreasing the number of repeated cuts.



 it shows whether the cutting head return to origin point after





finish a cutting command, press  and  for different Mode value. When it is show 1, it means cutting head will return to origin position after working. When the number is 0, it means the cutting head will stop in the behind of end point.


## Section 4 How to adjust distance between red laser dot or white laser dot and pen (Level 1 menu)

Press  to this page  , We can see the red


laser dot or white laser dot out. Upload material and put pen on the cutting head of machine, press the pen for down and up moving, to make a ink dot on the material.

Then press  button, screen display  ,

Press four direction buttons  ,  ,  ,  , to move the red laser dot coincide with the ink dot, if it can't coincide with the ink dot well, You can press



the origin button  for more than 4 seconds, and switch to point motion.



The motion distance is 0.1mm, and the adjustment effect is more accurate.

Press  to save the set parameters.








## Section 5 Cutting Proportion (Level 2 menu, it's good to keep factory setting if cutting work is good.)

Press  to the LCD interface , press the origin

button  to the LCD interface , the factory setting is W=0.00/H=0.00.



When contour cutting occurs, a blip scan a mark and can't scan the mark,


press button ,  to adjust "W" value, press button ,  to adjust "H" value.


After Adjust the value of W/H to 0.00, press button  to save the settings.


## Section 6 X, Y axis scale (Level 3 menu, please keep factory setting if the cutting work is good.)


Press button  to the interface  , press the origin

button  to the interface  , SX is the proportional coefficient of X axis, SY is the proportional coefficient of Y axis. Factory default is 0, if the cutting size is bigger or smaller than design size, you can adjust them by “Scale Calculator”.

Press  increase proportion of X axis.

Press  decrease the proportion of X axis.

Press  decrease the proportion of Y axis.

Press  increase the proportion of Y axis.



It needs to be set according to the actual situation. After adjustment, press to save the settings.

## Section 7 Cutting from FLASH

The file sent from the computer will be automatically saved into the built-in FLASH every time, power off will not be lost and for repeated cutting. No need the computer to send it





again. Press button to the interface .





Press button to start working on the last working file (**Note: FLASH cannot save files more than the machine's cache space**) .


## Section 8 U disk Working


Put the PLT file into the USB drive and insert the USB drive into the machine,

Press the button continuously  to the interface ,



Press the button  to the interface ,

Press 4 arrow keys to find the file you want to work on. The status display area displays

the file name and then press button  starts to work.

If there is no file, the interface display .


## Section 9 Pressure test


On the interface  Press the origin button , machine

will cut a rectangle, Check if the rectangle can be completely torn off or not ,in order to make sure the right pressure and the length of the blade tip.

## Section 10 Pause and Cancel during operating


LCD display  when working.

Press button  (the pause function) interface changes to



Coord  
X=0.00  
Coord  
Y=0.00

Press again  button to continue work.

Press this button when in the pause working  to cancel the present working.