How to refill the pretreatment

Open the top cover



Please check the tube connect to the pump is empty or not

If the tube is empty, So the pump inside will be enough air then the pump will be no power can not suck the pretreatment from the bottle to the spay head

Please do like below picture



This is the quick connector, Pull off the tube from the quick connector



Use the injection to suck up the water or pretreatment manually Then reconnect the tube to the quick connect again Now please confirm the water or pretreatment is full in the pump and the tube inside the train



Do the clean function, the Pump will be more power and spraying will be Okey again