



## ?????? ?????????? ??? LCD ??? ??????? ?? ?????? Copam CP2500/3500/3050/4050/4500

Item Code: CS-COP-CGS-R



FOB Price: **???7 019/???**

Mini Order: 1 ???.

Shipping Weight: **★★★★★**

Average Rating: 0.4lb (0.19kg)

[Inquire Now](#)

### Overview

**Cutting Strip for all COPAM Vinyl Sign Cutters**

**To be used with:** COPAM CP2500/3500/3050/4050/4500 Vinyl Sign Cutters

**Specifications:** 16M length, 8mm width

**Remarks:** Original



We recommend you change  
your cutting strip every:  
**6 Months**

(or when the strip is worn or frayed out).

Gouged & gunked up cutting strips will cost you vinyl. The process of changing them out can be tricky. Here's a step-by-step guide on how to change a cutting strip:

## HOW TO CHANGE A CUTTING STRIP

1



Use a **weeding hook**, **exacto knife** or another sharp pointed tool to pry up the existing cutting strip from one end.

2



Use **denatured alcohol** to clean out all the adhesive residue from the previous strip left in the channel.

3



When you lay in the new cutting strip, heat it up with a **heat gun** or **hair dryer** as you **squeegee** it into the channel.

4



Trim the end of the cutting strip to fit.

### What's the cutting guard strip for?

The cutting guard strip is used on the cutting plotter or vinyl cutter to protect the machine and the blade from being damaged. Without the strip, the cutting plotter will be badly scratched by the sharp blade and the blade will be abraded as well when the cutting plotter is working.

### How to stick the cutting guard strip on your machine?

First you should take off the old cutting guard strip and clean up the machine where the strip covered. Then you can cut a part of your new strip with the same length as your old one. At last, stick the guard strip on your machine with double-sided tape and press it.



Copyright © 1999-2012 by Beijing ChinaSigns Information Company Limited All Rights Reserved.

Email:info@sign-in-china.com Tel:+86 132 6410 3286 www.sign-in-china.com