

# 

#### Item Code: FMJ-2040-FM



## **Overview**

#### 

???????????

## **Specifications**

??????	FMJ-2040-FM
????. ?????? ??????????	2040??
????. ???????	23??
????????	0-5?/???
??????? ????	90??
?????? ??????	????

??????? ???????????????????????????????	
???????????????????????????????????????	AC 80-110?, ?? 110-240?, 50??/60??
???????????????????????????????????????	AC160
???	300??
???????????????????????????????????????	2200?1420 x 1120??
??????? ????????	(2360 x 1590 x 1270??) (????????????????) (2360 x 1590 x 1050??) (??????????????????????????????????
??? ??????	380??

# Tags

### 80" Flatbed Board Cold Laminator Machine Cold Laminator Machine

## QA

Q	For different film and glass thickness, will the pressure has to be different?	
A	Yes.	Reply by <u>sign-in-china</u>
Q	Do we need to readjust the pressure knob manually every time we change the film and glass thickness?	
A	Yes.	Reply by <u>sign-in-china</u>
Q	Will it be necessary and expensive to add programmable pressure adjusting system to the machine?	
A	There isn't programmable pressure adjusting system.	Reply by <u>sign-in-china</u>
Q	Does it need to use any wooden board to back up the glass panel when being laminated or just glass panel	el only?
A	There is the front and rear woking table makes the flatbed borad or glass going stably and safely.	Reply by sign-in-china
Q	Is there any of your customer using the machine to laminate safety film to glass and what are their experies machine?	ence to your
A	Yes, many clients do this, and they are satisfied with this machine.	Reply by <u>sign-in-china</u>
Q	Since we do not know the limitation of the machine. How can we be sure the machine work up to our stand	dard?

	Please read the USER MANUAL carefully before operation, lamination effect has big relation with operator's skill and laminating film quality.
	Reply by sign-in-china
A	
11	
Q	We plan to visit few company to observe the machine, will it be ok for your company for this visit?
A	Yes, sure, welcome. Reply by <u>sign-in-china</u>
Q	What is the dimension of core film of your machine?
A	The Core must be 3". Reply by <u>sign-in-china</u>



Copyright © 1999-2012 by Beijing ChinaSigns Information Company Limited All Rights Reserved.

Email:info@sign-in-china.com Tel:+86 132 6410 3286 www.sign-in-china.com