



# MT-FP6090-UV INSTALLATION AND OPERATION USER MANUAL

## CONTENT

### PART ONE INSTRUCTION

1-1 Structure And FunctionPag	e3
1-2 Front structure Page	e <b>4</b>
1-3 Back structurePage	e5

#### PART TWO INSTALLATION AND OPERATION

2-1 Before installationPage	e6
2-2 How to install ink systemPage	<del>)</del> 7
2-3 How to install the driverPage	<b>±10</b>
2-4 How to use the control panel Page	<b>±11</b>
2-5 How to install and operate the softwarePage	÷12
2-6 Printing and precautiousPage	<del>)</del> 22

### PART THREE MAINTENANCE AND TROUBLE SHOOTING

3-1 Maintence	Page24
3-2 Trouble Shooting	-Page25



### **Parameters**

Model: MT-FP6090-UV Printing Size: 23.6"\*35.4" Curing System: UV LED Lamp (Water cooling system) Max. Height: 5.5" Power: 50/60HZ 220V(±10%)<2A 110V(±10%)<4A Environment Requirement: 68-82°F HR40-60% Printer Head: Epson DX5 (Nozzles 180x8) X/Y/Z-Axix Motor: X/Y-Servor motor,Z-Stepping motor RIP: Photo Print RIP Computer Sys.: Microsoft Windows XP/Win7/win8-64bit Ink Color: K C M Y W W W Joint: USB2.0 N.W.: 321.93lb Machine Size: 55.1"\* 51.2"\*21.7"

### **Front Structure Figure**



### **Back Structure**



5

### **Preparation Before Installation**

- **1**. Put the machine on the table with at least **2**cm thickness and good stability.
- (Desktop instability will cause poor print quality )
- 2. Clean up the platform to make the surface clean.
- 3. Remove the corresponding fixed component following the diagram.
- 4. Printer shall be removed with Handles by 4-5 people.



Remove the Right Red Iron Sheets

Remove the left red iron sheets

1. Install the Ink Case



a.Unwrap the cables, and get the screws



c. Fix the screws of the ink case, place move the case as far as possible from the carriage

#### 2.Connect the Power Cable



a.Fix the cables here



b. Screw up the tube to the ink bottle



b.Place the ink case here



d. Check from side panel, and make sure the case will not block the carriage



c.Connect the power cable of white ink stirring system

#### 3. Refill the Ink to the Ink Bottle, and Lead it to Dampers:



a. Refill the ink



b.take off the damper cover



c. use the syringe to vacuum the ink out from the dampers

### Water Cooling System







NO.	Part	Quantity
1	Emergency Stop	1
2	Control Panel	1
3	Printing Table	1
4	Carriage Rail	1
5	Height Sensor	2
6	Belt Fastening	1
7	Printer Cover	1
8	UV LED	1
9	Damper	8
10	Manual Cleaning	1
11	Ink Bottle Case 1	
12	White Ink Stirrer	2
13	Ink Bottle	6

NO.	Part	Quantity
14	Carriage Motor	1
15	Wiper	1
16	Сар Тор	1
17	Water Cooling Case	1
18 Capping System Case 1		1
19	Capping System 1	
20	Waste Ink Pump 1	
21	Waste Ink Bottle 1	
22	2 Printer Head 1	
23	23 Fixture 2	
24	Handle 2	
25	Adjustment For Even	2
26	Dampers Cover	1

### How to Install the Driver

#### **Before Installation:**

Notes: Please closed or shut down all the anti-virus software before installation of the driver. Then copy UV-4060udisk file to computer. Power on printer, connect the USB cable and plug the USB dongle, please kindly follow the below steps:

#### How to Install it



#### FINISHED INSTALLATION

\* When finished installation, there will be a driver icon in the right bottom of PC. Right click on the icon, it will pop up a window to show the status: online or offline. When shows online, the printer is connected with computer, and ready for printing. When the icon is gone, please find the installation file, and right click to send the icon shortcut to desktop.



### **How to Use the Control Panel**

- \* Control panel is working when printer is online
- \* Below are the basic operation, and more info please check the more skill folder



\*FORWARD: Printer table move forwards

\*BACK: Printer table move back

\*LEFT:

1. Move the carriage to left side. Push it once, the carriage move once.

Push twice, printer head is still. Push third time, the printer head will move again.

2. It is the backward button also, when finished cleaning, push this button to the home page or the printer cannot print

\*RIGHT: Printer head move to right. But for this button cannot move the printer head back to home position, only the enter button can do it.

\*QUALITY: Adjust the printing quality. Enter this function, use the Left and Right to choose uni-direction or Bi-direction. Push the enter to confirm

\*CLEANING:

1.Cleaning: Push the cleaning button to enter this function.

Push enter, the printer head will start auto cleaning.

Push left button to backward the home page.

2. ink fill cleaning: push cleaning button to enter this function.

Push twice Back button then push the enter button to start the ink fill cleaning.

Push left button to backward the home page.

\*TEST: Push it once, Printer head will do a nuzzle test

\*MENU: Backup info and setting, usually we will not use this button

\*ENTER:

1. Confirm button.

2. Move the printer head back to home position

\*ORIGIN :

1. Default Origin is H75mmV0mm, please do not change it if not specific request

2. If the origin setting is changed, please reinstall the driver, then the origin will be reset to H75mmV0mm.

### 11

### **How to Install and Operate the Software**

\*Copy UV-4060disk into D disk, start printer, make USB line connected and plug dongle. \*Open"2. software" folder and install according to "installation instruction".

#### 1.Install and activate software on an online computer

1. Launch your browser and type https://www.saicloud.com in address bar and press enter, theninput your activation code, then click Activate, activation code can be found in the code labelin software package.

-		a sector of the
		ation code that accompanied your software purch
A	ctivation Code	5H4LALIJCZHTTW37YZDU

2. In login section, click I am new to the SAi Cloud and input your email address, then clickCreate Account, an email will be sent to your mailbox.

	<ul> <li>I am a returning custom</li> <li>I am new to the SAi Cloud</li> </ul>
	an new to the SALCIOU
Enter your e	mail address to get started.
Important:	The email address you select for
this SAi Clo	ud account will be the owner of
and a succession	e. It will be used for all SAi
	rvices. It is recommended you
use a perm	anent business email address.
78430	)6662@qq.com

3. Check your mailbox and click website link in the email then complete the information fields.

-		
-		
	Report for the set formation	
ign Paramet		
-		Terms And Conditions
Company have		Terms and Conditions
and a second		User Agreement
· Dami	Passe Cristen	MPORTMO-READ GAREFULLY
	smears U	This Account User's Appendix in upper contrary between You (defined below) and
		54 international Inc
Allene Line (		THE USHIG YOUR SA CLOUD ACCOUNT. YOU (AS THIS TERM IS DEFINED
Serve sre Z		BELOW) AGREE BY CLICKING ON THE "ACCEPT" BUTTON TO BE BOUND BY THE TERMS OF THIS AGREEMENT (AS THIS TERM IS DEFINED BELOW) ;
-		INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY DISCLAIMERS. LIMITATIONS OF LIABILITY, JURISDICTION, AND TERMINATION
		PROVISIONS. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, DO NOT OPEN AN SAI CLOUD ACCOUNT AND EXIT NOW
Swalling		Article 1. Defined Terms
In free		1. Account means your account on the SAI Cloud
-	_	<ol> <li>Agreement means the EAU User Account Agreement</li> <li>Entity means any individual garmenties part versus corporation limited.</li> </ol>
		ENLARGE No. 1 Instance Decline
Step	o 2. Add Soft	ware to your SAi Cloud Account
	Ad	Id To SAi Cloud Account
	This software lice	nse will be added to your SAI Cloud Account.
		Activate Now

4. Insert installation disk. It will be auto-played. If not, open Autorun disk. Then install software step by step by following the wizard.

1. Autorun Autorun Application SA International

Installation instructions:

1. To install Photoprint software, to open





#### 2.Then, next step:



Select "I accept the terms of the license agreement", then "Next"

i Production Suite		×	
License Agreement Please read the following license agreement carefully.			
Software License Agreement			
IMPORTANT (READ CAREFULLY: 1 contract between You (as defined below PhotoPRINT Software (as defined below This Agreement (as defined below) s the Software from SA International Inc. a using the Software. This Agreement app license; and (iii) original equipment manu the Software and other branded or custo BY OPENING THE SEALED PACKA DOWNLOADING THE SOFTWARE FR	v) and SA International Inc v). ets forth the terms and co and You (as defined below plies to any (I) single-user I ifacturer (DEM) or Special prized versions unless oth AGE CONTAINING THE S	c. for the Flexi and inditions for licensing of icense; (ii) multi-user Edition (SE) versions of herwise agreed. SOFTWARE OR	
I accept the terms of the license agree	and a second	Print	
I accept the terms of the license agree I do not accept the terms of the licens MISMETA	and a second	Print	

Find "Choose Destination Location" dialog box, and choose Destination Folder, then click "Next"



Above several options are necessary, another features can be selected according to different requirement. Click"Next"

PRODUCTION SUITE
eatures you do not want to install. Description

Keep default selection as above steps, do not choose other option, then "Next". Installing status will be shown as below.

Select Program Folder	PRODUCTION
Please select a program folder.	SUI
Setup will add program icons to the Program Fol name, or select one from the existing folders list.	
Program Folder:	CIER NEW IS COMMINDE.
SAi Production Suite	
Existing Folders:	
2777	
2222	
Accessories Administrative Tools	
Games	E
Maintenance	
PPLive	
SAI Production Suite	
Startup	3
alShield	
divincial	

When the program to run the installation is complete, as shown below:

Ai Production Suite Setup Status	
SAi Production Suite is configuring yo	our new software installation.
Installing	
C:\\SAi\SAi Production Suite\Prog	ram\Install Manager.exe
12	
stallShield	
(Venin/Lucine	Cancel

After completion of the program will run automatically pop up" Install Manager ", please choose according to the diagram , after the selection is complete click Done, as follows : From the next dialog box "Install Manger", click "OK".

Ins	tall: PhotoPRINT SERVER-PRO 10.5.2 PDF F	RIP (English)?
	Install to desktop	1
100	Clear Application's previous preferences	
-	Install to startup items	

Then installing continues, click "OK".

Choose your d	evice from the list below to add output profiles	Installer
	non W7200 W7250 W8200PG W6200PG ImagePROGRAF W6400 ImagePROGRAF W8400 ImagePROGRAF W8400D ImagePROGRAF IPF500 ImagePROGRAF IPF500 ImagePROGRAF IPF510 ImagePROGRAF IPF5100 ImagePROGRAF IPF5100 ImagePROGRAF IPF5100 ImagePROGRAF IPF5100 ImagePROGRAF IPF5100 ImagePROGRAF IPF5100	
File Size:	0 Bytes Reset	OK Cancel

Click "Finished" on next dialog box, as shown:.



Find the PhotoPrint DX software icon on desktop, and double click it. Then the software opens and comes the dialog box "Add Setup"

Choose a device type	
Color Printers	C Vinyl Cutters
C Hybrid Devices	
hoose a device	
What is the brand name of y	our color printer?
	•
What is the model name of y	our color printer?
	•

From the combo box "What is the model name of Apexjet Apexjet FlatBed, Then click "Next"

Choose a device type	
Color Printers     Hybrid Devices	C Vinyl Cutters
Choose a device	
What is the brand name of you Apexulet What is the model name of you	
Apeculat RatBod	

As below select "TCP/IP", Then on the pop-up dialog box "Communication", fill in "TCP/IP address" with "127.0.0.1", and click "OK".

What do	you want to call your new setup?		
	Apexulet FlatBed		
Do you w	ant to print to your ApexJet RatBed from other	applications?	
	T Yes, install the desktop driver		
How is yo	ur ApexUet RatBed connected to your comput	ter?	
	TCP/IP	Browse	
	Communication		
	TCP/IP address: 127 . 0 . 0	1	
	Port number: 9100	•	
		Cancel	

Finally click "Finish"

	PhotoPRINT SERVER-PRO	
	File     Edit     Setup     View     Help       Image: Setup     Image: Setup     Image: Setup     Image: Setup     Image: Setup       Wizard     Job ▼     RIP ▼     Send     Estimate     Nest     Unnest     Abort     Delete	Help ▼
	All ApexJet FlatBed_1 T	
Open Photoprint, Pop up this page drage a image into this area, double click the image to proceed further setting.	Setup     Job Name     Status     Sender       ApexJet FlatBed_1 網路尺寸jpg     Write port error. Administrato	
	+ # ApexJet FlatBed_1 客户打样.pdf Done Administrato ApexJet FlatBed_1 客户打样.pdf Done Administrato ApexJet FlatBed_1 客户打样.pdf Done Administrato	(1)
	P         11           RAM Fee: 166 GB         VM Free: 168 GB           VM Free: 168 GB         C. Free: 60.0 GB           D. Free: 120.6 GB         E. Free: 111.2 GB           RAM Total: 3.97 GB         VM Total: 2.00 GB           C. Total: 80.0 GB         D. Total: 129.0 GB           E. Total: 129.0 GB         E. Total: 129.0 GB	F: Frae: 116.0 F: Total: 127.8
Printing size setting, generally 60 and 90 cm.	Job Properties  Preset:  Media size  St totod = fel totode  90.000 m  90.000	, <u>15 ,10 ,5 ,0</u>
Image size setting	0.000 cm ÷ □ 0.000 cm ÷ 8 0.000 cm ÷ □ 0.000 cm ÷ 8 8 8 8 8 8 8 8 8 8 8 8 8 8	
The starting position Setting	Dual roll printing         8           Job Size         9           30, 514 cm         % 100, 000%           142.759 cm         % 100, 000%	
Copy image number and interval setting	Position Positi	
Mirror setting	Copies U Cop	
Image rotary		Cancer



### **Printing and Precautious**

#### 1) Pre-requisite

1. The printer is installed as previous description,

press test button to print the completed nozzel checking picture.

2. All software and driver installed. Open software and the machine is in online status.

#### 2) Printing process( For example: Print on cellphone case)

1.Sample placement: Make the cellphone case surface cleaned and place in the platform position (1cm,1cm).



Precautious :

- 1. The sample surface should be clean.
- 2. Use pre-treatment solution oil on glass or some metals before printing.
- 3. Use bi-direction printing for flat surface Use uni-direction for curved surface.

4. Flat bottom sample can be directly placed on the platform and easily moveable should be fixed by tape or moulds. The leather or plastic film should use vacuum table.

5. Check UV brightness according to sample distortion. Generally set at 40. Easily heated and distorted set at 20-30. In the real operation, use the lowest brightness at curing. Low brightness can prolong the UV Lamp lifetime.

2. Image Option and rework:

Choose HD image. If required, rework image to make image size and shape suitable for cellphone case.

#### Pre-cautious

HD image can improve the printing quality.
 Adjust the image size and share to fit the sample.

3. Add image brightness and contrast ratio in Photoshop for better quality.

4. If print spot color, build spot color channel in Photoshop in advance.



#### 3. Software Content Settings:

Drag the image into the Photoprint, Set the pic size, the start print position(1cm,1cm), with reference to Page11--- "Software Installation and Use"

60.0000 x 40.1	JUUUcm	-
😝 60.000 cm	🚖 🚺 40.000 cm	
0.000 cm	🚔 🧮 0.000 cm	(
0.000 cm	💭 🛄 0.000 cm	(A) (A)
Dual rol	l printing	
ob size		Í
🛅 16,000 cm	🚖 % 99.882%	
11 8.000 cm	<b>%</b> 99.882%	
📜 🗌 Fit to m	edia 👖 🗹 Proporti	onal
osition		
]+ 1.000cm	🚔 📮 1.000 cm	-
opies		Í
1.	🗦 🚼 0.254 cm	
Page range:		
7 Page nesting	-	

4. Prepare the Machine:

Adjust the height of the printhead from the printing surface to 1-2mm, Turn on the UV lamp, adjust the brightness, if necessary, can send a job to print.



#### Cautions.

- 1. The pic size and position setting, and direction.
- 2. Select whether to use Mirror Printing.
- 3. Select whether to save after printing.
- 4. Select ICC file and resolution, general choose 720\*720 resolution.
- 5. Select the use of white ink;
- 6. Select the Overlay or Underneath.

This section may refer to Page11---"Software Installation and Use."

Cautions :

Machine Parts:

- Adjust the distance between the printhead and the printing surface: general is 1-2mm, When printing plane thermal deformation, should elevate moderately in advance. Genaral printing height can be adjusted by the height switch, the transparent & hollow samples should be adjusted mannully.
- 2. Select the Uni-direction or Bi-direction according to the sample flatness.
- 3. Adjust the brightness of UV light according to the samples degree of deformation and ink amount.

Reference video: https://www.youtube.com/watch?v=YS2b98zFB\_E

#### **1**. Continuous use and maintenance requirements

Daily Task	1.Do a cleaning, check the nozzles. 2 Clean up wiper and rubber parts of Cap Top.	https://www.youtube.com/ watch?v=59vLBEtVMLY https://www.youtube.com/ watch?v=AVzehgadhKI
Weekly Task	<ol> <li>Clean encoder strip.</li> <li>Clean the surface of UV light.</li> </ol>	https://www.youtube.com/ watch?v=O7yFdrJotFo
Monthly Task	1.Add lubricating oil to rails and wheel(X/Y/Z).	https://www.youtube.com/ watch?v=21nWwTcqgCY
Seasonly Task	<ol> <li>Replace the Cap Top.</li> <li>Replace the wiper.</li> <li>Replace the damper.</li> <li>Clean the UV light.</li> </ol>	https://www.youtube.com/wat ch?v=_wGiUOp5g2s https://www.youtube.com/wat ch?v=nc6BBUzSQFA https://www.youtube.com/wat ch?v=VaEOob7rPSo https://www.youtube.com/wat ch?v=OBaa5rW209c
Year Task	1.Replace the carraige	https://www.youtube.com/ watch?v=p3rMhb8lQuI

#### 2. Discontinuous use and maintenance requirements

Without use in a week	1. Spray anti-rust oil to rails and wheel(X/Y/Z).	https://www.youtube.co m/watch?v=sjSIPT1raq c
Without use in a month	1.Clean up ink tubes. 2.Remove prinprinthead wipe it with clean cloth and keep in dark place.	https://www.youtube.com/wa tch?v=OBaa5rW209c https://www.youtube.com/wa tch?v=URmI5hua-34

### Q1: The checklist for nozzles when test strip not complete



Step 1: Do a small cleaning, press TEST to check the nozzles. If there is more than 10% break line of a certain color, follow Step 2.	https://www.youtube.com/watch?v=59vLBEtVMLY
Step 2: Replace the corresponding damper of the break line color. Do small cleaning, press TEST to print a test strip. If still exist the problem, follow Step 3.	https://www.youtube.com/watch?v=VaEOob7rPS o https://www.youtube.com/watch?v=59vLBEtVMLY
Step 3: Replace Cap Top. Do small cleaning and press TEST to check nozzles. If still exist a problem, contact us.	https://www.youtube.com/watch?v=_wGiUOp5g2 s https://www.youtube.com/watch?v=59vLBEtVMLY



Step 1: Check the control panel if it is as shown at right pic. If not, press LEFT back to main interface, as right pic. Then resend the print job. If it is already the right pic, do Step 2.	H 75mm U Ømm BI-DIR
Step 2: Reconnect the USB cable, then restart the printer. If still exist a problem, contact us.	



## www.apex-jet.com E-mail:support@apex-jet.com Tel: +86-755-28220390





Youtube

Facebook