

LED Rubik's Cube screen instructions

first step

Scan the QR code to download



Scan the QR code to download

Second step

Connect to the WiFi of the Rubik's Cube screen before use

MCBOX



Third step

Open the APP for the first time, enter the default password 123456 if you can't connect, you can connect several times



Fourth step

New program "+"



Fifth step

Choose a style, the APP has a built-in advertising template, you can choose to use the template, double-click to change the content and color in the template



Choose a style



Double click to modify the template internal trade



sixth step


When not using the template, you can click to create it freely. Choose Rubik's Cube type, installation method, four-sided and five-sided universal



Select screen type, confirm



Add content



Edit the content, complete by yourself, click to publish



Seventh step

Click on the large remote control screen to switch programs. Select, stop broadcast, rotate broadcast, delete specified program



Eighth step, cube box setting

